




# DIGITAL VIDEO RECORDER 8- AND 16-CHANNEL MODELS USER'S MANUAL





**WARNING****RISK OF ELECTRIC SHOCK  
DO NOT OPEN**

**WARNING:** TO REDUCE THE RISK OF ELECTRIC SHOCK,  
DO NOT REMOVE COVER (OR BACK).  
NO USER-SERVICEABLE PARTS INSIDE.  
REFER SERVICING TO QUALIFIED  
SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

**COMPLIANCE NOTICE OF FCC:**

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE, IN WHICH CASE USERS WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT THEIR OWN EXPENSE.

**WARNING:** CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

THIS CLASS OF DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE-CAUSING EQUIPMENT REGULATIONS.

The information in this manual is believed to be accurate as of the date of publication. ATV® is not responsible for any problems resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this publication may be issued to incorporate such changes.

## Important Safeguards

### 1. Read Instructions

All the safety and operating instructions should be read before the appliance is operated.

### 2. Retain Instructions

The safety and operating instructions should be retained for future reference.

### 3. Cleaning

Unplug this equipment from the wall outlet before cleaning it. Do not use liquid aerosol cleaners. Use a damp soft cloth for cleaning.

### 4. Attachments

Never add any attachments and/or equipment without the approval of the manufacturer as such additions may result in the risk of fire, electric shock or other personal injury.

### 5. Water and/or Moisture

Do not use this equipment near water or in contact with water.

### 6. Accessories

Do not place this equipment on an unstable cart, stand or table. The equipment may fall, causing serious injury to a child or adult, and serious damage to the equipment. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.



This equipment and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the equipment and cart combination to overturn.

### 7. Power Sources

This equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power, please consult your equipment dealer or local power company.

### 8. Power Cords

Operator or installer must remove power and TNT connections before handling the equipment.

### 9. Lightning

For added protection for this equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the equipment due to lightning and power-line surges.

### 10. Overloading

Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

### 11. Objects and Liquids

Never push objects of any kind through openings of this equipment as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the equipment.

### 12. Servicing

Do not attempt to service this equipment yourself. Refer all servicing to qualified service personnel.

### 13. Damage requiring Service

Unplug this equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- A. When the power-supply cord or the plug has been damaged.
- B. If liquid is spilled, or objects have fallen into the equipment.
- C. If the equipment has been exposed to rain or water.
- D. If the equipment does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the equipment to its normal operation.
- E. If the equipment has been dropped, or the cabinet damaged.
- F. When the equipment exhibits a distinct change in performance — this indicates a need for service.

### 14. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

### 15. Safety Check

Upon completion of any service or repairs to this equipment, ask the service technician to perform safety checks to determine that the equipment is in proper operating condition.

### 16. Field Installation

This installation should be made by a qualified service person and should conform to all local codes.

### 17. Correct Batteries

Warning: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

### 18. Tmra

A manufacturer's maximum recommended ambient temperature (Tmra) for the equipment must be specified so that the customer and installer may determine a suitable maximum operating environment for the equipment.

### 19. Elevated Operating Ambient Temperature

If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the manufacturer's maximum rated ambient temperature (Tmra).

### 20. Reduced Air Flow

Installation of the equipment in the rack should be such that the amount of airflow required for safe operation of the equipment is not compromised.

### 21. Mechanical Loading

Mounting of the equipment in the rack should be such that a hazardous condition is not caused by uneven mechanical loading.

### 22. Circuit Overloading

Consideration should be given to connection of the equipment to supply circuit and the effect that overloading of circuits might have on over current protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.

### 23. Reliable Earthing (Grounding)

Reliable grounding of rack mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

# Table of Contents

<b>Chapter 1 — Introduction .....</b>	<b>1</b>
Features .....	1
Technical Overview .....	1
<b>Chapter 2 — Installation .....</b>	<b>3</b>
Package Contents .....	3
Required Installation Tools .....	3
Video Input .....	3
Video Loop Through .....	4
Audio In/Out .....	4
Video Out .....	4
RS232C Port .....	4
Network Port .....	4
RS485 Port .....	5
Alarm Input/Output .....	5
USB Ports .....	5
Factory Reset Switch .....	6
Power Cord Connector .....	6
<b>Chapter 3 — Configuration .....</b>	<b>7</b>
Front Panel Controls .....	7
Camera Buttons (1 to 16) .....	7
HDD LED .....	7
Alarm Out LED .....	7
NETWORK LED .....	8
Clip Copy LED .....	8
POWER LED .....	8
PANIC Button .....	8
ALARM Button .....	8
CLIP COPY Button .....	8
ZOOM/PTZ Button .....	8
DISPLAY/SPOT Button .....	8
GROUP/SEQUENCE Button .....	8
PLAYBACK Button .....	9
MENU/CAMEO Button .....	9
Arrow Buttons .....	9
PLAY/PAUSE Button .....	9
Turning on the Power .....	9
Initial Unit Setup .....	10
Setup Screen .....	10
System Information .....	11
Date/Time Setup .....	13
Storage Screen .....	15

User Setup Screen .....	17
Shutdown Screen .....	19
Logout Screen .....	20
Network & Notification Setup.....	20
Network Screen .....	20
LAN Setup Screen.....	21
Modem Setup .....	23
DVRNS Setup .....	24
WebGuard Setup.....	25
Notification Setup .....	25
Configuring Devices .....	27
Camera Setup Screen.....	28
Audio Setup Screen .....	29
Alarm-Out Screen.....	30
Display Screen .....	31
Remote Control Screen .....	33
Recording Settings .....	34
Record Screen .....	34
Schedule Screen .....	35
Pre-Event Screen .....	38
Event Settings .....	39
Alarm-In Screen .....	39
Motion Detection Screen .....	41
Video Loss Screen .....	44
Text-In Screen.....	46
System Event Screen .....	49
Event Status Screen.....	52
<b>Chapter 4 – Operation .....</b>	<b>55</b>
Turning on the Power .....	55
Live Monitoring .....	55
PIP Mode.....	55
Active Cameo Mode .....	55
Freeze Mode .....	56
Zoom Mode .....	56
Image Adjustment .....	56
Sequence Mode .....	56
Event Monitoring .....	57
Covert Camera .....	57
Spot Monitoring .....	57
PTZ Mode.....	58
Using a Mouse .....	59
Recording Video .....	60
Recording Audio.....	60
Playing Recorded Video.....	60
Searching Video .....	61

---

Go to the Date/Time .....	62
Calendar Search .....	62
Event Log Search .....	63
Text-In Search .....	65
Motion Search .....	67
Clip-Copy Screen .....	68
<b>Appendix A — USB Hard Disk Drive Preparation .....</b>	<b>71</b>
Preparing the USB hard disk drive in Windows 2000.....	71
Preparing the USB hard disk drive in Windows 98.....	71
<b>Appendix B — Text-In Search Examples .....</b>	<b>72</b>
Search Example I .....	72
Search Example II .....	72
<b>Appendix C — WebGuard.....</b>	<b>74</b>
Web Monitoring Mode .....	75
Web Search Mode.....	76
<b>Appendix D — Time Overlap .....</b>	<b>78</b>
<b>Appendix E — Troubleshooting.....</b>	<b>79</b>
<b>Appendix F — Connector Pin Outs .....</b>	<b>80</b>
I/O Connector Pin Outs .....	80
RS485 Connector Pin Outs .....	80
<b>Appendix G — Map of Screens .....</b>	<b>81</b>
<b>Appendix H — System Log Notices .....</b>	<b>82</b>
<b>Appendix I — Error Code Notices.....</b>	<b>83</b>
<b>Appendix J — Specifications .....</b>	<b>84</b>

## List of Illustrations

Figure 1 — Typical DVR installation. ....	2
Figure 2 — 16-Channel DVR rear panel. ....	3
Figure 3 — 16-Channel DVR front panel. ....	7
Figure 4 — Login screen. ....	10
Figure 5 — Setup screen. ....	10
Figure 6 — Virtual Keyboard. ....	11
Figure 7 — Information screen. ....	11
Figure 8 — Upgrade screen. ....	12
Figure 9 — Setup Import screen. ....	12
Figure 10 — Setup Export screen. ....	12
Figure 11 — System Log screen. ....	13
Figure 12 — Date/Time setup screen. ....	13
Figure 13 — Holiday setup screen. ....	14
Figure 14 — Time Sync. screen. ....	15
Figure 15 — Storage Information screen. ....	16
Figure 16 — Device Format screen. ....	16
Figure 17 — Device Information screen. ....	16
Figure 18 — Storage Status screen. ....	17
Figure 19 — User setup screen. ....	18
Figure 20 — New Group setup screen. ....	18
Figure 21 — New User setup screen. ....	19
Figure 22 — Shutdown screen. ....	20
Figure 23 — Logout screen. ....	20
Figure 24 — Network Menu. ....	20
Figure 25 — Network setup screen. ....	20
Figure 26 — LAN (Manual) setup screen. ....	21
Figure 27 — Port Numbers setup screen. ....	22
Figure 28 — LAN (DHCP) setup screen. ....	22
Figure 29 — LAN (ADSL) setup screen. ....	23
Figure 30 — Modem setup screen. ....	23
Figure 31 — DVRNS setup screen. ....	24
Figure 32 — WebGuard setup screen. ....	25
Figure 33 — Notification Mail setup screen. ....	26
Figure 34 — Authentication setup screen. ....	26
Figure 35 — Notification Callback setup screen. ....	27
Figure 36 — Devices Menu. ....	27
Figure 37 — Camera setup screen. ....	28
Figure 38 — Camera PTZ setup screen. ....	28
Figure 39 — PTZ Device list. ....	29
Figure 40 — Port Setup window. ....	29
Figure 41 — Audio setup screen. ....	29
Figure 42 — Alarm-Out Settings screen. ....	30
Figure 43 — Alarm-Out Schedule screen. ....	30
Figure 44 — Display OSD screen. ....	31
Figure 45 — OSD Margin screen. ....	32
Figure 46 — Main Monitor screen. ....	32
Figure 47 — Spot Monitor screen. ....	33
Figure 48 — Remote Control setup screen. ....	33



Figure 49 — Record menu.....	34
Figure 50 — Record setup screen.....	34
Figure 51 — Schedule (Simple Mode) setup screen.....	35
Figure 52 — Schedule (Advanced Mode) setup screen.....	36
Figure 53 — Schedule — Settings (Advanced Mode) setup screen.....	37
Figure 54 — Default (Advanced Mode) setup screen.....	37
Figure 55 — Pre-Event setup screen.....	38
Figure 56 — Event menu.....	39
Figure 57 — Alarm-In Settings screen.....	39
Figure 58 — Alarm-In Actions 1 screen.....	40
Figure 59 — Alarm-In Notify menu.....	40
Figure 60 — Alarm-In Actions 2 screen.....	41
Figure 61 — Motion Detection Settings screen.....	41
Figure 62 — Motion Detection Sensitivity screen.....	42
Figure 63 — Motion Detection Min. Blocks screen.....	42
Figure 64 — Motion Detection Zone screen.....	42
Figure 65 — Motion Detection Zone menu.....	42
Figure 66 — Daytime Setup screen.....	43
Figure 67 — Motion Detection Actions 1 screen.....	43
Figure 68 — Motion Detection Actions 2 screen.....	44
Figure 69 — Video Loss Settings screen.....	44
Figure 70 — Video Loss Actions 1 screen.....	45
Figure 71 — Video Loss Actions 2 screen.....	46
Figure 72 — Text-In Settings screen.....	46
Figure 73 — Text-In Device Settings screen.....	47
Figure 74 — Text-In Actions 1 screen.....	48
Figure 75 — Text-In Actions 2 screen.....	49
Figure 76 — Health Check screen.....	49
Figure 77 — Check Recording screen.....	50
Figure 78 — Storage screen.....	50
Figure 79 — S.M.A.R.T Setup screen.....	51
Figure 80 — System Event Actions screen.....	51
Figure 81 — Event Status screen.....	52
Figure 82 — Sequence menu.....	57
Figure 83 — PTZ Select Camera menu.....	58
Figure 84 — PTZ Preset screen.....	58
Figure 85 — Preset View screen.....	58
Figure 86 — PTZ menu.....	58
Figure 87 — Mouse menu.....	59
Figure 88 — Mouse Display menu.....	59
Figure 89 — Search menu.....	62
Figure 90 — Go to the Date/Time screen.....	62
Figure 91 — Calendar Search screen.....	62
Figure 92 — Event Log Search screen.....	63
Figure 93 — Event Log Search Option screen.....	64
Figure 94 — Text-In Search screen.....	65
Figure 95 — Text-In Search Option screen.....	66
Figure 96 — Motion Search screen.....	67
Figure 97 — Motion Search Option screen.....	67
Figure 98 — Clip-Copy screen.....	69

Figure 99 — WebGuard login screen.....	74
Figure 100 — WebWatch screen. ....	75
Figure 101 — WebSearch screen.....	76

# Chapter 1 — Introduction

## Features

Your color digital video recorder (DVR) provides recording capabilities for eight or 16 camera inputs. It provides exceptional picture quality in both live and playback modes, and offers the following features:

- 8 or 16 Composite Video Input Connectors
- Compatible with Color (NTSC or PAL) and B&W (CCIR and EIA-170) Video Sources
- Auto Detection for NTSC and PAL
- Multiple Monitor Connectors: 1 BNC Video Out, 1 Spot, 1 VGA
- Multiple Search Engines (Date/Time, Calendar, Event)
- Records up to 120/100 Images per Second (NTSC/PAL)
- “Loop-Through” Video Connectors
- Continuous Recording in Disk Overwrite Mode
- 2 USB 2.0 Ports
- Continues Recording while Transmitting to Remote Site and during Playback
- User-friendly Graphical User Interface (GUI) Menu System
- Multiple Recording Modes (Time-lapse, Pre-event, Alarm, Motion and Panic)
- 2-Channel Audio Recording and 1-Channel Audio Playback
- Text Input for ATM and POS
- Alarm Connections Include: Input, Output and Reset Input
- Built-in Alarm Buzzer
- Live or Recorded Video Access via Ethernet or Modem
- Time Synchronization using industry standard protocol
- Built-in CD-RW Drive
- Self-diagnostics with automatic notification including hard disk drive S.M.A.R.T. protocol

## Technical Overview

In addition to replacing both a time-lapse VCR and a multiplexer in a security installation, your DVR has many features that make it much more powerful and easier to use than even the most advanced VCR.

The DVR converts analog NTSC or PAL video to digital images and records them on a hard disk drive. Using a hard disk drive allows you to access recorded video almost instantaneously; there is no need to rewind tape. The technology also allows you to view recorded video while the DVR continues recording video.

Digitally recorded video has several advantages over analog video recorded on tape. There is no need to adjust tracking. You can freeze frames, fast forward, fast reverse, slow forward and slow reverse without image streaking or tearing. Digital video can be indexed by time or events, and you can instantly view video after selecting the time or event.

Your DVR can be set up for event or time-lapse recording. You can define times to record, and the schedule can change for different days of the week and user defined holidays.

The DVR can be set up to alert you when the hard disk drive is full, or it can be set to record over the oldest video once the disk is full.

Your DVR uses a proprietary encryption scheme making it nearly impossible to alter video.

You can view video and control your DVR remotely by connecting via Ethernet. There are two USB ports that can be used to upgrade the system or copy video clips to external hard disk, CD-RW and flash drives.

**NOTE: This manual covers the 8- and 16-channel digital video recorders. The DVRs are identical except for the number of cameras and alarms that can be connected and the number of cameras that can be displayed. For simplicity, the illustrations and descriptions in this manual refer to the 16-camera model.**




Figure 1 — Typical DVR installation.

## Chapter 2 — Installation

### Package Contents

The package contains the following:

- Digital Video Recorder
- Power Cord
- User's Manual (This Document)
- RAS Software CD and User's Manual
- Rack-mount Kit
- Assembly Screws and Guide Rails for Adding Hard Disk Drives

### Required Installation Tools

No special tools are required to install the DVR. Refer to the installation manuals for the other items that make up part of your system.




Figure 2 — 16-Channel DVR rear panel.

- |                        |                        |                |                      |
|------------------------|------------------------|----------------|----------------------|
| ① Video Input          | ② Video Loop Through   | ③ Audio In/Out | ④ Video Out          |
| ⑤ RS232C Port          | ⑥ Network Port         | ⑦ RS485 Port   | ⑧ Alarm Input/Output |
| ⑨ Factory Reset Switch | ⑩ Power Cord Connector |                |                      |

Your DVR can be used with either NTSC or PAL equipment.

**NOTE: You cannot mix NTSC and PAL equipment. For example you cannot use a PAL camera and an NTSC monitor.**

#### Video Input



Connect the coaxial cables from the video sources to the BNC Video In connectors.

## Video Loop Through



If you would like to connect your video source to another device, you can use the Loop BNC connectors.

**NOTE: The Loop BNC connectors are auto terminated. Do NOT connect a cable to the Loop BNC unless it is connected to a terminated device because it will cause poor quality video.**

## Audio In/Out



Your DVR can record audio from up to two sources. Connect the audio sources to Audio In 1 and Audio In 2 as needed using RCA jacks. Connect Audio Out to your amplifier.

**NOTE: It is the user's responsibility to determine if local laws and regulations permit recording audio.**

**NOTE: The DVR does not have amplified audio output, so you will need a speaker with an amplifier. The DVR does not have a pre-amplifier for audio input, so the audio input should be from an amplified source, not directly from a microphone.**

## Video Out




A VGA connector is provided so that you can use a standard, multi-sync computer monitor as your main monitor. Use the cable supplied with your monitor to connect it to the DVR.



Connect the main monitor to the Video Out connector. Connect the spot monitor to the SPOT connector as needed.

**NOTE: The VGA and Video Out (BNC) connectors may be connected to individual monitors for simultaneous operation.**

## RS232C Port



An RS232 port is provided to connect an external modem for remote monitoring, configuration and software upgrades, and to connect a remote control keyboard. Use a modem cable with a DB-9S (female) connector to connect to the DVR. See *Chapter 3 — Configuration* for configuring the modem.

**NOTE: The DVR is not supplied with a modem cable, and many modems are not supplied with cables. Make certain you have the correct cable when purchasing the modem.**

## Network Port



The DVR can be networked using the 10/100Mb Ethernet connector. Connect a Cat5 cable with an RJ-45 jack to the DVR connector. The DVR can be networked with a computer for remote monitoring, searching, configuration and software upgrades. See *Chapter 3 — Configuration* for configuring the Ethernet connections.



**CAUTION: The network connector is not designed to be connected directly with cable or wire intended for outdoor use.**

## RS485 Port



The DVR can be controlled remotely by an external device or control system, such as a control keyboard, using RS485 half-duplex serial communications signals. The RS485 connector can also be used to control PTZ (pan, tilt, zoom) cameras. Connect RX-/ TX- and RX+/TX+ of the control system to the TX-/RX- and TX+/RX+ (respectively) of the DVR. See *Chapter 3 — Configuration* and the PTZ camera or remote controller manufacture's manual for configuring the RS485 connection.

## Alarm Input/Output



**NOTE:** To make connections on the Alarm Connector Strip, press and hold the button and insert the wire in the hole below the button. After releasing the button, tug gently on the wire to make certain it is connected. To disconnect a wire, press and hold the button above the wire and pull out the wire.

**AI 1 to 16 (Alarm-In):** You can use external devices to signal the DVR to react to events. Mechanical or electrical switches can be wired to the AI (Alarm-In) and GND (Ground) connectors. The threshold voltage of electrical switches for NC (Normally Closed) is above 2.4V and for NO (Normally Open) is below 0.3V, and should be stable at least 0.5 seconds to be detected. The voltage range of alarm input is from 0V to 5V. See *Chapter 3 — Configuration* for configuring alarm input.

**GND (Ground):** Connect the ground side of the Alarm input and/or alarm output to the GND connector.

**NOTE:** All the connectors marked GND are common.

**NC/NO (Relay Alarm Outputs):** The DVR can activate external devices such as buzzers or lights. Connect the device to the C (Common) and NC (Normally Closed) or C and NO (Normally Open) connectors. NC/NO is a relay output which sinks 2A@125VAC and 1A@30VDC. See *Chapter 3 — Configuration* for configuring alarm output.

**ARI (Alarm Reset In):** An external signal to the Alarm Reset In can be used to reset both the Alarm Out signal and the DVR's internal buzzer. Mechanical or electrical switches can be wired to the ARI (Alarm Reset In) and GND (Ground) connectors. The threshold voltage is below 0.3V and should be stable at least 0.5 seconds to be detected. Connect the wires to the ARI (Alarm Reset In) and GND (Ground) connectors.

## USB Ports




Two USB ports on the front panel are provided to connect external hard disk, CD-RW or flash drives for video clip copying or system upgrades. Position external drives close enough to the DVR so that you can make the cable connections, usually less than 6 feet. Use the USB cable provided with the hard disk drive to connect it to the DVR.

A USB mouse (not supplied) can be connected to one of the ports. You can use the mouse to navigate through the screens and menus much like you would on a computer.

A USB to Serial converter can be connected to the USB port. Multiple text-in devices can be used with a USB to Serial converter.

## Factory Reset Switch



The DVR has a **Factory Reset** switch to the left of the Alarm Output connectors on the rear panel. This switch will only be used on the rare occasions that you want to return all the settings to the original factory settings.

**CAUTION:** When using the *Factory Reset*, you will lose any settings you have saved.


To reset the unit, you will need a straightened paperclip:

1. Turn the DVR off.
2. Turn it on again.
3. While the DVR is initializing, the front panel LEDs will blink. When the front panel LEDs blink, poke the straightened paperclip to the unlabeled hole in the left of the Alarm Output connectors.
4. Hold the switch until all the LEDs on the front panel are lit.

**NOTE:** When the DVR successfully resets to factory defaults all the LEDs on the front panel flash five times.

5. Release the reset switch. All of the DVR's settings are now at the original settings it had when it left the factory.

## Power Cord Connector



Connect the AC power cord to the DVR and then to a wall outlet.

**WARNING:** ROUTE POWER CORDS SO THAT THEY ARE NOT A TRIPPING HAZARD. MAKE CERTAIN THE POWER CORD WILL NOT BE PINCHED OR ABRADED BY FURNITURE. DO NOT INSTALL POWER CORDS UNDER RUGS OR CARPET.

**THE POWER CORD HAS A GROUNDING PIN. IF YOUR POWER OUTLET DOES NOT HAVE A GROUNDING PIN RECEPTACLE, DO NOT MODIFY THE PLUG. DO NOT OVERLOAD THE CIRCUIT BY PLUGGING TOO MANY DEVICES IN TO ONE CIRCUIT.**

Your DVR is now ready to operate. Refer to *Chapter 3 — Configuration* and *Chapter 4 — Operation*.



## Chapter 3 — Configuration

**NOTE:** Your DVR should be completely installed before proceeding. Refer to *Chapter 2 — Installation*.

### Front Panel Controls




Figure 3 — 16-Channel DVR front panel.

- |                         |                        |                       |                |
|-------------------------|------------------------|-----------------------|----------------|
| ① Camera Buttons        | ② HDD LED              | ③ Alarm Out LED       | ④ Network LED  |
| ⑤ Clip Copy LED         | ⑥ Power LED            | ⑦ Panic Button        | ⑧ Alarm Button |
| ⑨ Clip Copy Button      | ⑩ Zoom/PTZ Button      | ⑪ Display/SPOT Button |                |
| ⑫ Group/Sequence Button | ⑬ Playback Mode Button | ⑭ Menu/Cameo Button   |                |
| ⑮ Arrow Buttons         | ⑯ Play/Pause Button    | ⑰ USB Connectors      |                |

The front panel looks and operates much like a VCR combined with a multiplexer. Many of the buttons have multiple functions. The following describes each button and control. Take a few minutes to review the descriptions. You will use these to initially set up your DVR and for daily operations.

**NOTE:** You can also use a USB mouse (not supplied) to navigate through the screens and menus much like you would on a computer.

#### Camera Buttons (1 to 16)

Pressing the individual camera buttons will cause the selected camera to display full screen. Buttons 1 to 9 are also used to enter passwords.

In the PTZ mode, pressing the button 1 zooms in the screen and the button 2 zooms out the screen, pressing the button 3 focuses near and button 4 focuses far, and pressing the button 5 moves to the preset and button 6 saves the preset.

#### HDD LED

The HDD LED flickers when the DVR is recording or searching video on the hard disk drive.

#### Alarm Out LED

The Alarm Out LED is lit when alarm output or internal buzzer is activated.

## NETWORK LED

The NETWORK LED is lit when the unit is connected to a network via Ethernet.


## Clip Copy LED

The Clip Copy LED is lit when the DVR is clip-copying.

## POWER LED

The POWER LED is lit when the unit is On.

## PANIC Button

Pressing the **PANIC** button starts panic recoding of all camera channels, and displays  on the screen. Pressing the button again will stop panic recording.


## ALARM Button

The **ALARM** button has two functions. First, it will reset the DVR's outputs including the internal buzzer during an alarm. Second, it will display the event log when you are in the live monitoring mode unless there is an active alarm. This operation can be user password protected.

## CLIP COPY Button

Pressing the **CLIP COPY** button allows you to copy video clips.

## ZOOM/PTZ Button

Pressing the **ZOOM/PTZ** button zooms in the current image in double on the screen. You can use the arrow buttons to move the rectangle to another area. Pressing the  (Play/Pause) button zooms in the image in rectangle.

Pressing and holding the button for two seconds or longer enters the PTZ (Pan/Tilt/Zoom) mode and the PTZ icon flickers. Pressing the button again exits the PTZ mode. Pressing the arrow buttons or **MENU/CAMEO** button allows you to control properly configured cameras.

## DISPLAY/SPOT Button




Pressing the **DISPLAY/SPOT** button toggles between different display formats. The available formats are: PIP, 2x2, 3x3 and 4x4.

Pressing and holding the button for two seconds or longer allows you to select which cameras will display on the Spot monitor.

## GROUP/SEQUENCE Button


When in the live mode, pressing the **GROUP/SEQUENCE** button changes the screen from the current camera group to the next camera group, and the screen displays the page number. Pressing and holding the button for two seconds or longer displays live channels sequentially.

## PLAYBACK Button

Pressing the **PLAYBACK** button enters the playback mode, and pressing the button again exits the playback mode. When entering the playback mode, video is paused. Pressing the  (Play/Pause) button plays back video at regular speed. The screen displays  when the DVR is in the Pause mode and the screen displays  when the DVR is playing back video.

## MENU/CAMEO Button

Pressing the **MENU/CAMEO** button enters the **Setup** screen. You will need to enter the authorized user and password to access Setup. Pressing the button also closes the current menu or setup dialog box. In the Playback mode, pressing the button displays the Search menu.

















Pressing and holding the button for two seconds or longer enters the cameo mode. The yellow outline surrounding the video indicates the active cameo, and pressing the arrow buttons moves the active cameo. Pressing the desired camera button in the active cameo edits the cameo and displays the video of selected camera. Pressing the  (Play/Pause) button exits the Active Cameo mode. Selecting **Exit Group Edit** in the cameo menu displayed when pressing the **MENU/CAMEO** button also exits the Active Cameo mode.

**NOTE: A cameo is defined as any cell within multi-screen display. The cameo mode allows you to change the screen layout by editing the cameo.**





## Arrow Buttons

These buttons are used to navigate through menus and GUI. You can also use them to change numbers by highlighting a number in the menu and using the **Up** and **Down** arrow buttons to increase or decrease the number's value.

These buttons are also used to control Pan and Tilt when in the PTZ mode. When in the PIP display format, pressing the **Up** and **Down** arrow buttons moves the position of the small screen counter-clockwise and clockwise, and pressing the **Left** and **Right** buttons changes the PIP screen size.

In the playback mode, pressing the  button plays video backward at high speed. Pressing the button again toggles the playback speed from ,  and . The screen displays ,  and  respectively. Pressing the  button plays video forward at high speed. Pressing the button again toggles the playback speed from ,  and . The screen displays ,  and  respectively. When in the pause mode, pressing the  button moves to the next image and pressing the  button moves to the previous image.

## PLAY/PAUSE Button




In the live monitoring mode, pressing the  button freezes the current screen and the screen displays  icon. When in the playback mode, pressing the  button plays back images at regular speed or pauses playing video. Pressing the  button selects a highlighted item or completes an entry that you have made during system setup.

## Turning on the Power


Connecting the power cord to the DVR turns on the unit. The unit takes approximately 60 seconds to initialize.

## Initial Unit Setup

Before using your DVR for the first time, you will want to establish the initial settings. This includes items such as time and date, display language, camera, audio, remote control, record mode, network and password. Your DVR can be set up using various screens and dialog boxes.

Throughout the screens you will see . Highlighting the  and pressing the  (Play/Pause) button gives you the opportunity to reset that screen to its default settings.

Press the **MENU** button to enter the setup screens. The Login screen appears.





Select a User and enter the password by pressing the appropriate combination of Camera number buttons and then the  button. There is no default password when logging in the admin user for the first time.

Figure 4 — Login screen.

**NOTE:** To assure the secure management of the system, setting up a password is strongly recommended.

**NOTE:** You can use a mouse (not supplied) to access the *Login* screen in addition to using the front panel buttons. Click the right mouse button to display the *Login* screen. To enter a password, click the  button, and the virtual keyboard displays. See instructions below for using the virtual keyboard.

## Setup Screen




Figure 5 — Setup screen.

Press the **MENU** button to enter the setup screen. While setting up the DVR, there will be many opportunities to enter names and titles. When making these entries, a Virtual Keyboard will appear.



Figure 6 — Virtual Keyboard.

Use the arrow keys to highlight the character you want in the name or title and press the button. That character appears in the title bar and the cursor moves to the next position. Pressing toggles between the upper and lower case keyboards, backspaces, and deletes entered characters. You can use up to 31 characters including spaces in your title.

Special characters can be created using ^ and a capital letter; e.g., ^J for NL (New Line), ^M for CR (Carriage Return). Special characters are commonly used by text input devices and will be useful when performing Text-In Searches.

## System Information

Highlight Information and press the button. The Information screen appears.

Figure 7 — Information screen.

In the Information screen, you can name the site location, assign a System ID number, select the language the screens are displayed in, display software version number, upgrade the software, show the System Log, display recorded time data, and clear all data.

Highlight the Site box and press the button. A virtual keyboard appears that you can use to enter a Site Name.


Once you have entered your title, highlight Close and press the button.


Highlight the box beside System ID and press the button. Change the number by highlighting it and using the Up and Down arrow buttons to increase and decrease the number from 0 to 99.


**NOTE: The System ID number is used to identify the unit when it is connected with other DVRs through the RS485 port. You cannot use the same ID number for two or more DVRs that are in the same RS485 network. It is possible to have multiple DVRs with System ID 0 that are in the same area as long as they are not part of an RS485 network.**

Highlight the box beside Language and press button. A drop-down menu displays the available languages. Highlight the desired language and press the button.

The box beside Version displays the software version of the DVR.

To upgrade the software, connect a USB device containing the upgrade package file to the DVR. Highlight **Upgrade...** and press the  button. The **Upgrade** screen appears.



The screen displays the upgrade package file names that are available. The “.rui” indicates that the file is for software upgrades and “.ofi” indicates that the file is for optical drive firmware upgrades. Select the desired file and press the  button.




Highlighting the **Install** button and pressing the  button will install the selected software package. Highlighting the **Cancel** button and pressing the  button will close the window without upgrading the software. If the upgrade package file is not installed on the DVR properly, you will get an error message. The system restarts automatically after completing the upgrade.

Figure 8 — Upgrade screen.

**NOTE:** The **Upgrade** button will be deactivated if the hard disk drive has not been formatted as it requires the space for temporary files when upgrading the system.

**CAUTION:** The USB device must be **FAT16** or **FAT32** format.

You can import saved DVR settings or export the current DVR settings. To import saved DVR settings, connect the USB device containing the setup file (.dat) to the DVR. Highlight **Setup – Import...** and press the  button.





Select the desired setup file and press the **Import** button to import the selected settings and change the DVR settings accordingly. Highlight **Include Network Setup** and press the  button to toggle between On and Off. When set to Off, the network settings will not be changed.

Figure 9 — Setup Import screen.

To export the current DVR settings, connect the USB device to the DVR. Highlight **Setup – Export...** and press the  button.




Highlight the box beside **File name** and press the  button. A virtual keyboard allows you to enter the file name. Selecting **Export** will save the current settings in .dat file format on the USB device.

Figure 10 — Setup Export screen.

**NOTE:** Even after changing the DVR settings by importing saved settings, the time-related settings (Date/Time, Time Zone and Daylight Saving Time) will NOT be changed.

**CAUTION:** The USB device must be **FAT16** or **FAT32** format.

Highlight **Show System Log...** and press the  button to display the System Log.

System Log		
Time	Type	
08/28/2007 11:43:28	Setup Begin	
08/28/2007 11:43:28	Login : admin	
08/28/2007 11:43:14	Boot Up	
08/27/2007 15:58:25	Shutdown	
08/27/2007 15:58:20	Logout : admin	
08/27/2007 15:42:04	Setup End	
08/27/2007 15:16:14	Setup Begin	
08/27/2007 15:05:15	Setup End	
08/27/2007 14:49:16	Setup Begin	
08/27/2007 14:49:14	Login : admin	
1 / 16		
Close		






The System Log screen lists system activities (up to 5,000 from the latest) that have occurred along with the time and date. The  icon will be displayed in the last column for system activities of the remote site. You can scroll through the log pages by using the Up and Down arrows, or you can go directly to a log page by entering the log page number in the box at the bottom left of the screen. Highlight **Close** and press the  button to exit the screen.


Figure 11 — System Log screen.

The box beside **Recorded Data – From / To** displays the time information of recorded data.

Highlighting **Clear All Data...** and pressing the  button will clear all video data. You will be asked to verify that you wish to clear all data before the DVR erases the video data. **Clear All Data...** will not clear the System Log.



After you are finished with the Information Screen, you can highlight **Save** and press the  button to save the changes and exit the screen. If you do not wish to save the changes, highlight **Cancel** and press the  button to exit the screen.



## Date/Time Setup

Highlight **Date/Time** in the System menu and press the  button. The **Date/Time** setup screen appears.

Date/Time			
Date/Time	Holiday	Time Sync.	
Date	08/28/2007	Format	
Time	11:48:18	Format	
Time Zone	GMT-05:00 Eastern Time (US & Ca)		
	<input checked="" type="checkbox"/> Use Daylight Saving Time		
<div>Save</div> <div>Cancel</div>			

Figure 12 — Date/Time setup screen.

Highlight the first box beside **Date** and press the  button. The individual sections of the date will highlight. Use the **Up** and **Down** arrow buttons to change the number. Use the **Left** and **Right** arrow buttons to move between month, date and year. Once you have the correct date, press the  button.

Highlight the **Format** box beside **Date** and press the  button. Select from the three available date formats and press the  button to save your selected format.

Highlight the first box beside **Time** and press the  $\odot$  button. The individual sections of the time will highlight. Use the **Up** and **Down** arrow buttons to change the number. Use the **Left** and **Right** arrow buttons to move between hour, minutes and seconds. Once you have the correct time, press the  $\odot$  button.

Highlight the **Format** box beside **Time** and press the  $\odot$  button. Select from the three available time formats and press the  $\odot$  button to save your selected format.

**NOTE: The clock will not start running until you have highlighted **Save** and pressed the  $\odot$  button.**

Highlight the box beside **Time Zone** and press the  $\odot$  button. Select your time zone from the list and press the  $\odot$  button.

Highlight **Use Daylight Saving Time** and press the  $\odot$  button. Pressing the  $\odot$  button toggles between **On** and **Off**.

Highlight the **Holiday** tab, and the Holiday setup screen appears.

No.	Date	X
		X
		X
		X
		X
		X
		X
		X
		X

Save Cancel

Figure 13 – Holiday setup screen.

You can set up holidays by highlighting **+** and pressing the  $\odot$  button. The current date appears.

Highlight the month and day and change them by using the **Up** and **Down** arrow buttons. Press the  $\odot$  button to add the date. Dates can be deleted by highlighting the **X** beside the date and pressing the  $\odot$  button.

**NOTE: Holidays that do not fall on the same date each year should be updated once the current year's holiday has passed.**

Highlighting the **Time Sync.** tab causes the Time Sync. screen to display. You can set up time synchronization between the DVR and standard time servers that are available in most time zones and countries, or between the DVR and another DVR.



Figure 14 — Time Sync. screen.

Highlight the box beside **Automatic Sync.** and press the  $\odot$  button. This toggles between On and Off.

Highlight the box beside **Time Server** and press the  $\odot$  button. A virtual keyboard appears that you can use to enter the IP address or domain name of the time server.

**NOTE: You can use the domain name instead of IP address if you already set up the DNS Server when setting up the LAN.**

Highlight the box beside **Interval** and press the  $\odot$  button. Set the time interval for synchronization from 30 minutes to 1 day at various time intervals.

**Last Sync-Time** displays the last time the DVR was synchronized with the time server.

Highlight **Run as Server** and press the  $\odot$  button. Pressing the  $\odot$  button toggles between On and Off. When it is On, the DVR you are setting up will run as a time server.

You can save your changes by highlighting **Save** and pressing the  $\odot$  button. Selecting **Cancel** exits the screen without saving the changes.

## Storage Screen

Highlight **Storage** in the System menu and press the  $\odot$  button. The **Storage** setup screen appears and displays information about the DVR's storage devices.







Figure 15 – Storage Information screen.

The information in the **Type** column describes the storage device.

The capacity of the storage device is displayed in the **Capacity** column.

The **Format** column displays whether the device is used for recording (**Record**) or not (**Not Using**). **Not Formatted** indicates the device is not formatted.  indicates when the device has temporary space set aside so that video clips can be saved on a CD-RW or DVD RW.

Highlight the box in the **Format** column for the desired storage device and press the  button.




You will be able to format the device for recording. When selecting **Not Using** from **Use As** and highlighting the **Format** button, the device will not be used for recording. You can also set aside space to store temporary files for CD or DVD burning by selecting **Partition – CD/DVD Burn**.


Figure 16 – Device Format screen.

**NOTE: The DVR does NOT support USB hard disk drives with a version lower than 2.0.**

**NOTE: System upgrades require formatting internal hard disk drives.**

The **Information** column displays whether the device is being used or not. **Other** indicates the device has been used for another DVR.

Highlight the box in the **Information** column for the desired storage device and press the  button.




You will be able to check the time information about recorded data. If you want to erase recorded data on the selected device, highlight **Clear** and press the  button. You will be asked whether or not you want to delete the data.

Figure 17 – Device Information screen.

Highlight the **Status** tab, and the Storage Status screen displays.

Storage			
Information		Status	
Type	Disk Bad	Temperature	S.M.A.R.T.
Internal 1	Not Formatted	Good (38 °C)	Good
Internal 2	Not Formatted	Good (38 °C)	Good

Close

Figure 18 — Storage Status screen.

The **Type** column displays the type of storage device.

The **Disk Bad** column displays the percentage of bad sectors. **Not Formatted** indicates the device is not formatted.


The **Temperature** column displays the temperature of the storage device.

The **S.M.A.R.T.** column displays “Good”, “Bad” or “N/A”, depending on storage conditions.


- Good — The storage condition is normal.
- Bad — Data cannot be written on or read from the storage device.
- N/A — Storage conditions are normal, however, the S.M.A.R.T. monitoring is not working or supported.

**NOTE:** When the storage condition is “Bad”, the **Event Status – Storage** screen displays and you can check the storage condition for details. Once the “Bad” message displays, replacing the hard disk drive is recommended, usually within 24 hours.

**NOTE:** *Temperature* and *S.M.A.R.T.* information will be available only for internal hard disk drives supporting the **SMART (Self-Monitoring Analysis and Reporting Technology)** monitoring program.

Selecting **Close** and pressing the  button exits the screen.

## User Setup Screen

Highlight **User** in the **System** menu and press the  button. The **User** setup screen displays the authorized groups and users. You can add and delete groups and users. When adding a group, you can assign authority levels to the group.




Figure 19 – User setup screen.

The +/- column is used to collapse and expand user groups. If there is a + or – in this column, it indicates the item is a Group Name. If there is a – in front of the Group Name, it indicates that the group has been “expanded” and all of the User Names within that group are displayed below the Group Name. If there is a + in front of the Group Name, it indicates that the group has been “collapsed” and all of the User Names within that group are hidden. To collapse or expand a group, highlight the +/- column in front of the desired group and press the button.


Highlighting a Group Name and pressing the button allows you to change the authority levels assigned to the group.

**CAUTION: Write down the new password and save it in a secure place. If the password is forgotten, the unit must be reset using the *Factory Reset Button* and all data settings will be lost.**

Highlighting a User Name and pressing the button allows you to add or change the password assigned to that user. You can also change the group to which the user is assigned.

The column can be used to delete a User Name or an entire Group. If the is grayed out, that Group or User cannot be deleted. Highlight the and press the button. You will be asked to confirm that you want to delete the User or Group. To delete the User currently logged into the DVR on a local system or a PC running RAS, log the user out of the system first and then delete the user.

To add a Group, highlight the + Group... box and press the button. A virtual keyboard appears allowing you to enter the Group name.





You can use up to 15 characters including spaces in the group name. Enter the name and assign authority levels to the group. Highlighting the Authority box and pressing the button will toggle between all authority levels being turned On and Off. Highlighting the individual authority level boxes and pressing the button will toggle between that authority level being turned On and Off.

Figure 20 – New Group setup screen.

The authority levels that can be turned On and Off are:

- **Shutdown** — The user can shut the system down on a local system.
- **Upgrade** — The user can upgrade the software on a local system or a PC running RAS.
- **System Time Change** — The user can change the system date and time on a local system or a PC running RAS.
- **Data Clear** — The user can clear all video data or format disks on a local system or a PC running RAS.
- **Setup** — The user without Setup authority cannot establish any system settings excluding system shutdown and logout on a local system or a PC running RAS.
- **Color Control** — The user can control brightness, contrast, hue and saturation for cameras on a local system or a PC running RAS.
- **PTZ Control** — The user can control the PTZ camera on a local system or a PC running RAS.
- **Alarm-Out Control** — The user can reset the DVR's outputs including the internal buzzer during an alarm by pressing the **ALARM** button on a local system or alarm-out control button on a PC running RAS.
- **Covert Camera View** — The user can view video from cameras set as Covert while in the Live Monitoring or Search mode on a local system or a PC running RAS.
- **System Check** — The user can view the remote system status or check the remote system status as a batch process on a PC running RAS.
- **Record Setup** — The user can establish all Record settings on a local system or a PC running RAS.
- **Search** — The user can access the Search mode on a local system or a PC running RAS.
- **Clip-Copy** — The user can copy video clips on a local system or a PC running RAS, and save video data in an AVI, bitmap or JPEG file format.

To add a User, highlight the **+ User...** box and press the  button. A virtual keyboard appears allowing you to enter the User Name.




The 'New User' dialog box contains the following fields and controls:

- User:** A text input field with a blacked-out placeholder.
- Group:** A dropdown menu currently showing 'Administrator'.
- Password:** A text input field with a small '...' button to its right.
- Confirm:** A text input field with a small '...' button to its right.
- Buttons:** 'OK' and 'Cancel' buttons at the bottom.


Enter the name and assign the User to a Group and password. You can use camera buttons 1 to 9 on either the front panel to assign the password. The password can be up to 8 digits. You will be asked to confirm the password.

Figure 21 — New User setup screen.


**NOTE:** In addition to using the front panel buttons, you can use the virtual keyboard to assign the password. To display the virtual keyboard click the  button using the mouse (not supplied).


Highlighting the box beside **Auto Login** allows you to select a User to be automatically logged in when the DVR is powered up. It can also be set to never automatically login a user.

Highlighting the box beside **Auto Logout** allows you to select from a list of times that the user will be automatically logged out. The options are: Never, 1 min., 3 min., 5 min., 10 min., 15 min., 20 min., 25 min., 30 min. and 1 hr.

You can save your changes by highlighting **Save** and pressing the  button. Selecting **Cancel** exits the screen without saving the changes.

## Shutdown Screen

Highlight **Shutdown** in the System menu and press the  button. The Shutdown screen displays asking you to confirm whether or not you want to shut the system down.





After selecting Shutdown and pressing the  button, a screen will appear telling you when it is safe to disconnect power.

Figure 22 — Shutdown screen.

## Logout Screen

Highlight Logout in the System menu and press the  button. The Logout screen displays asking you to confirm whether or not you want to log out the current user.




After selecting Logout and pressing the  button, the user will be logged out.

Figure 23 — Logout screen.


## Network & Notification Setup

In the Main screen, use the Left or Right arrow buttons to display the Network menu.



Figure 24 — Network Menu.

## Network Screen

Highlight Network in the Network menu and press the  button. The Network setup screen displays. You will be able to change the Network, LAN, Modem and DVRNS settings.







Figure 25 — Network setup screen.

Highlight the first box beside Transfer Speed. Press the Up and Down arrow buttons to set the Transfer Speed from 50Kbps to 100Mbps.

Highlight the second box beside **Transfer Speed**. You can select the unit of measure for the transfer speed between: **bps** and **ips**. Press the  button to set the transfer speed.


Highlight the box beside **Quality** and press the  button. You can select the Quality from: **Very High**, **High**, **Standard** and **Basic**. Press the  button to set the Quality.

**NOTE: The higher Quality settings require higher Transfer Speed settings. The transfer speed you set is the maximum speed. Depending on the network environment, this speed may not be achieved.**

**NOTE: The local recording speed might be affected by various network bandwidth (Transfer Speed) conditions.**



## LAN Setup Screen

Highlight the LAN tab, and the LAN screen displays.



The image shows a 'Network' configuration window with several tabs: 'Network', 'LAN' (which is selected), 'Modem', 'DVRNS', and 'WebGuard'. Inside the 'LAN' tab, there is a 'Type' dropdown menu set to 'Manual'. Below this, there are three input fields with up/down arrow buttons: 'IP Address' (192.168.1.129), 'Gateway' (192.168.1.254), and 'Subnet Mask' (255.255.255.0). Further down is a 'DNS Server' field set to '0.0.0.0' with up/down arrows. Below the DNS field is a button labeled 'Port Number Setup...'. At the bottom right of the window are 'Save' and 'Cancel' buttons.

Figure 26 — LAN (Manual) setup screen.

Highlight the box beside **Type** and press the  button. You can select the type of network configuration from: **Manual**, **DHCP** and **ADSL (with PPPoE)**. Select the desired type and press the  button.

Selecting **Manual** from the **Type** allows you to set up LAN parameters manually.


**NOTE: You will need to get the appropriate IP Address, Gateway and Subnet Mask from your network administrator.**


Change the numbers by highlighting them and using the **Up** and **Down** arrow buttons to increase or decrease the number.

The factory default LAN settings are:

IP Address:	192.168.1.129
Gateway:	192.168.1.254
Subnet Mask:	255.255.255.0

Highlight the box beside **DNS Server**. Press the **Up** and **Down** arrow buttons to set the IP address of the DNS server.

Highlight the **Port Number Setup...** box and press the  button. The **Port Number Setup** screen appears.



Change the numbers by highlighting them and using the Up and Down arrow buttons to increase or decrease the number. The factory default Port settings are:

Remote Admin:	8200
Remote Callback:	8201
Remote Watch:	8016
Remote Search:	10019

Figure 27 — Port Numbers setup screen.

**NOTE:** You will need to get the appropriate Port Numbers for each RAS and WebGuard related program (Admin, Callback, Watch and Search) from your network administrator.

**NOTE:** The system restarts automatically after changing the port settings.

**NOTE:** Do NOT use the same port number for two different programs, otherwise, the DVR cannot be connected with the PC running RAS or WebGuard.

**CAUTION:** When changing the port settings, you must change the port settings on the PC running RAS or WebGuard as well. Refer to the RAS manual for details.

Selecting DHCP from the Type and highlighting Save button reads the current IP address of the DVR configured by DHCP (Dynamic Host Configuration Protocol) network.




Figure 28 — LAN (DHCP) setup screen.

Selecting ADSL (with PPPoE) allows you to set up the ADSL network.

**NOTE:** ADSL and modem cannot be configured at the same time. If the DVR is configured by modem, the ADSL (with PPPoE) will not be selected.



Figure 29 — LAN (ADSL) setup screen.

Highlight the box beside **ID** and press the button. A virtual keyboard appears allowing you to enter the ID for ADSL connection.

Highlight the box beside **Password** and press the button. A virtual keyboard appears allowing you to enter the password for ADSL connection.

**NOTE:** Entering the *ID* and *Password* and highlighting **OK** reads the current IP address of the DVR configured by the ADSL network.

**NOTE:** If the DVR is configured for DHCP or an ADSL network, the IP address of the DVR might change whenever the unit is turned on.


## Modem Setup

Highlight the Modem tab, and the Modem screen displays.


Figure 30 — Modem setup screen.


**NOTE:** If the RS232 port is in use for remote control, networking cannot be configured for a modem.

Highlight **Enable** and press the button to toggle between On and Off. You will only be able to change the settings if Modem is enabled.

Highlight the box beside **Baud Rate** and press the  button. A list of baud rates ranging from 300 to 115,200 appears.

Highlight the box beside **Data Bit** and press the  button. Choose between 7 bit and 8 bit formats.

Highlight the box beside **Stop Bit** and press the  button. Choose between 1 and 2 Stop Bits.

Highlight the box beside **Parity** and press the  button. A drop-down list appears. You can select from None, Odd or Even parity.

## DVRNS Setup

Highlight the DVRNS tab, and the DVRNS screen displays.





The image shows a software window titled "Network" with several tabs: "Network", "LAN", "Modem", "DVRNS", and "WebGuard". The "DVRNS" tab is selected. Inside the window, there is a checkbox labeled "Use DVR Name Service" which is checked. Below this, there is a text field for "DVRNS Server" containing "2dvr.com". To its right is a "Port" field with a value of "10088" and a range "(10000 ~ 12000)". Below the port field is an unchecked checkbox for "Use NAT". Further down, there is a "DVR Name" field with a "Check" button to its right. Below that is a "Help Desk" field. At the bottom right of the window are "Save" and "Cancel" buttons.

Figure 31 — DVRNS setup screen.

**NOTE:** When LAN settings have been changed, set up the DVRNS after saving your LAN changes by highlighting **Save** and pressing the  button.


Highlight **Use DVR Name Service** and press the  button to toggle between On and Off.


**NOTE:** The DVRNS (DVR Name Service) allows the DVR to use Dynamic IP addresses for remote connection. When this feature is On, you can access your DVR remotely using the DVR name instead of its IP address. For the DVRNS feature, the DVR should be registered on the DVRNS server.

Highlight the box beside **DVRNS Server** and press the  button. A virtual keyboard appears allowing you to enter the IP address or domain name of the DVRNS server.

**NOTE:** You will need to get the IP Address or domain name of the DVRNS Server from your network administrator.


**NOTE:** You can use the domain name instead of IP address if you already set up the DNS Server when setting up the LAN.

Highlight the box beside **Port** and press the  button. Set the port number of the DVRNS server using the Up and Down arrow buttons to increase or decrease the numbers.

Highlight **Use NAT** and press the  button to toggle between On and Off.

**NOTE: When using the NAT (Network Address Translation) device, refer to the NAT manufacturer's instructions for the proper network settings.**

Highlight the box beside DVR Name and press the  button. A virtual keyboard appears allowing you to enter the DVR name to be registered on the DVRNS server.

Highlight the Check box and press the  button to check whether or not the name you entered can be used.


**NOTE: The DVR name you entered should be checked by selecting *Check*, otherwise the DVRNS changes will not be saved.**

**NOTE: When entering no name or a name already registered on the DVRNS server, an error message displays.**

Highlighting Save and pressing the  button registers the DVR on the DVRNS server. Proper DVRNS settings will display the help desk information of the DVRNS server in the box beside Help Desk.


## WebGuard Setup


Highlight the WebGuard tab, and the WebGuard screen displays.



The screenshot shows the 'WebGuard' tab selected within a 'Network' configuration window. The window has tabs for 'Network', 'LAN', 'Modem', 'DVRNS', and 'WebGuard'. The 'WebGuard' tab is active, displaying a checkbox labeled 'Use WebGuard Service' which is currently unchecked. Below this is a 'Port' field with a numeric value of '12088' and a range '(12000 ~ 14000)'. To the right of the port field are up and down arrow buttons. At the bottom right of the window are 'Save' and 'Cancel' buttons.

Figure 32 — WebGuard setup screen.

Highlight Use WebGuard Service and press the  button to toggle between On and Off. See *Appendix C—WebGuard* for detailed descriptions of the WebGuard service.

Highlight the box beside Port and press the  button. Set the port number used when accessing WebGuard by using the Up and Down arrow buttons to increase or decrease the numbers.

You can save your Network changes by highlighting Save and pressing the  button. Selecting Cancel exits the screen without saving the changes

## Notification Setup

The DVR can be set up to send an email or to contact a computer running RAS (Remote Administration System) when an event occurs.


Highlight Notification in the Network menu and press the  button. The Notification screen displays. You will be able to change the Mail and Callback settings.

Figure 33 — Notification Mail setup screen.

Highlight **Enable** and press the  $\odot$  button to toggle between On and Off. You will only be able to change the settings if Mail is enabled.

Highlight the box beside **SMTP Server** and press the  $\odot$  button. A virtual keyboard appears that you can use to enter the IP address or domain name of the SMTP server.

**NOTE: You will need to get the IP Address or domain name of the SMTP Server from your network administrator.**

**NOTE: You can use the domain name instead of IP address if you already set up the DNS Server when setting up the LAN.**

Highlight the box beside **Port** and press the  $\odot$  button. Use the arrow buttons to enter the SMTP Server port number obtained from your system administrator. The default port number is 25.

Highlight **Use SSL/TLS** and press the  $\odot$  button to toggle between On and Off. When it is On, the DVR can send an email via an SMTP server requiring SSL (Secure Sockets Layer) authentication.

Highlight the box beside **Authentication** and press the  $\odot$  button. An Authentication screen appears.

Highlight **Use** and press the  $\odot$  button to toggle between On and Off. Highlight the box beside **User/Password** and press the  $\odot$  button. A virtual keyboard appears allowing you to enter the user ID and password.

Figure 34 — Authentication setup screen.

Highlight the box beside **Sender** and enter the sender's e-mail address. Use the virtual keyboard to enter the e-mail address.

**NOTE: The e-mail address must include the "@" character to be a valid address.**

Highlight the box beside **Recipient** and enter the recipient's e-mail address. Use the virtual keyboard to enter the e-mail address.

Highlight the **Callback** tab, and the Callback screen displays.

No.	IP Address
1	0.0.0.0
2	0.0.0.0
3	0.0.0.0
4	0.0.0.0
5	0.0.0.0

Figure 35 — Notification Callback setup screen.

Highlight **LAN** and press the  $\odot$  button to toggle between On and Off. When LAN is turned On you can change the IP addresses.

Highlight the **IP Address** box that you want to change and press the  $\odot$  button. Enter the IP address of the computer you want contacted during an event. You can enter up to five IP addresses.

Highlight the box beside **Retry** and enter the number of times you would like the DVR to try contacting the computer. You can select from 1 to 10 retries.

If the modem was enabled in the Network screen, you can set up the DVR to contact a computer running RAS. Highlight **Modem** and press the  $\odot$  button to toggle between On and Off. When Modem is turned On you can enter a telephone number.

Highlight the box beside **Remote Server Phone Number** and enter the telephone number of the computer running RAS.

Highlight the box beside **Outside Line Call** and enter any numbers that must be dialed for an outside line for your telephone system; for example, “9”.

Highlight the box beside **Callback Phone Number** and enter the telephone number of the DVR.

You can save your Notification changes by highlighting **Save** and pressing the  $\odot$  button. Selecting **Cancel** exits the screen without saving the changes.


## Configuring Devices


You can configure the video, audio, alarm, display and remote control devices connected to the DVR.



Figure 36 — Devices Menu.

## Camera Setup Screen

Highlight Camera in the Devices menu and press the  button. The Camera setup screen appears.



The screenshot shows the 'Camera' setup window with the 'Settings' tab selected. It contains a table with 8 rows, each representing a camera. Each row has a checkbox, a number, a title, and a 'Use' dropdown menu. All checkboxes are checked, and all 'Use' dropdowns are set to 'Normal'. At the bottom, there are 'Save' and 'Cancel' buttons, and a back arrow button on the left.

<input type="checkbox"/>	No.	Title	Use
<input checked="" type="checkbox"/>	1	CAM1	Normal
<input checked="" type="checkbox"/>	2	CAM2	Normal
<input checked="" type="checkbox"/>	3	CAM3	Normal
<input checked="" type="checkbox"/>	4	CAM4	Normal
<input checked="" type="checkbox"/>	5	CAM5	Normal
<input checked="" type="checkbox"/>	6	CAM6	Normal
<input checked="" type="checkbox"/>	7	CAM7	Normal
<input checked="" type="checkbox"/>	8	CAM8	Normal


Figure 37 — Camera setup screen.

You can turn the camera number On or Off, and you can change the Title of each camera using the virtual keyboard. You can also determine which cameras will display on the monitors by selecting Normal, Covert 1 or Covert 2 from a drop-down list in the Use column.

**NOTE:** When selecting the *Covert 1*, the DVR displays the camera title and status icons on the covert video. When selecting the *Covert 2*, the DVR displays only camera title on the covert video.

**NOTE:** A user who does not have *Covert Camera View* authority cannot view video from cameras set to *Covert 1* or *Covert 2* in both the live monitoring and playback modes.

Highlight the PTZ tab, and the PTZ setup screen displays.




The screenshot shows the 'Camera' setup window with the 'PTZ' tab selected. It contains a table with 8 rows, each representing a camera. Each row has a number, a 'Product' dropdown menu, and an 'ID' dropdown menu. All 'Product' dropdowns are set to 'None'. Below the table, there is a 'Port' dropdown menu set to 'None' and a 'Setup...' button. At the bottom, there are 'Save' and 'Cancel' buttons, and a back arrow button on the left.


No.	Product	ID
1	None	0
2	None	0
3	None	0
4	None	0
5	None	0
6	None	0
7	None	0
8	None	0

Port: None    Setup...

Figure 38 — Camera PTZ setup screen.

**NOTE:** You will only be able to set up PTZ devices if the PTZ port is set to RS232 or RS485. You will not be able to use a modem if you are using the RS232 port for PTZ control.

Highlight the box in the Product column for the PTZ camera you wish to configure and press the  button. A list of PTZ devices appears.






Select your camera from the list and press the  button. You will need to connect the camera to the RS232 or RS485 connector on the back of the DVR following the camera manufacturer's instructions.

Figure 39 – PTZ Device list.

You can assign IDs to each camera by highlighting the box under the ID heading and pressing the  button. Change the number by highlighting it and using the Up and Down arrow buttons to increase and decrease the number. The PTZ ID number can be set from 0 to 256.

Highlight the Setup... box and press the  button. The Port Setup window appears.




Configure the port's setting based on the PTZ camera manufacturer's instructions.

Figure 40 – Port Setup window.

You can save your Camera changes by highlighting Save and pressing the  button. Selecting Cancel exits the screen without saving the changes.

## Audio Setup Screen

Highlight Audio in the Devices menu and press the  button. The Audio setup screen appears.






Figure 41 – Audio setup screen.

The DVR can record up to two audio inputs. Highlight the box beside the input and press the  button. A list of cameras appears, and you can select which camera you want associated with that audio input.

Highlight Enable Audio-Out and press the  button. This toggles between enabling and disabling audio out.

**NOTE: The DVR will NOT record audio when the recording speed is set to less than 1 ips.**

You can save your Audio changes by highlighting **Save** and pressing the  $\odot$  button. Selecting **Cancel** exits the screen without saving the changes.

## Alarm-Out Screen

Highlight **Alarm-Out** in the **Devices** menu and press the  $\odot$  button. The **Alarm-Out** screen allows you to change the settings and establish a schedule for each alarm output from the DVR.

No.	Title	Type
1		NO
2		NO

Dwell Time: 5 sec.

Figure 42 — Alarm-Out Settings screen.

Each alarm output can be given its own title by highlighting the box under the **Title** heading and pressing the  $\odot$  button. A virtual keyboard appears allowing you to enter the title.

Highlighting the boxes under the **Type** heading allows to set the alarm output for NO or NC (normally open or normally closed).

Highlighting the box beside **Dwell Time** and pressing the  $\odot$  button allows you to set the dwell time of the alarm output. Dwell times range from 5 seconds to 15 minutes.

Highlighting the **Schedule** tab causes the **Schedule** screen to display.

No.	Day	Range	Mode	Channels
1	All	00:00 ~ 24:00	Event	1, 2, Beep

+

Figure 43 — Alarm-Out Schedule screen.

You can add and edit alarm output schedules on this screen. Highlight the **+** and press the  $\odot$  button to add a schedule. Highlighting the boxes under the **Column** heading and pressing the  $\odot$  button allows you to edit the information in those boxes.



The **Day** box allows you to select the days that the alarm schedule will be active. The choices are: Sun, Mon, Tue, Wed, Thu, Fri, Sat, M~F, Hol and All.

The **Range** box allows you to set the time that the alarm schedule will be active in 15-minute increments from 00:00 to 24:00.

The **Mode** box allows you to set how the alarm reacts during the scheduled time. When set to **On**, the Alarm-Out is active during the scheduled time. When set to **Event**, the Alarm-Out is only active when there is an Event during the scheduled time.

The **Channels** box allows you to set which alarm outputs will be active. You can also select the DVR's internal buzzer.

The **X** box allows you to delete an alarm output schedule. You will be asked to confirm whether or not you really wish to delete the schedule.

You can save your Alarm-Out changes by highlighting **Save** and pressing the **Y** button. Selecting **Cancel** exits the screen without saving the changes.

## Display Screen

Highlight **Display** in the Devices menu and press the **Y** button. The **Display** screen allows you to select what information will be displayed on the monitor.





Figure 44 — Display OSD screen.


Highlighting an item and pressing the **Y** button toggles that item On and Off. When an item is On, there is a checkmark in the box beside it. The following items can be turned On or Off:

- **Zoom** — The icon displays on the enlarged video.
- **Network** — The icon displays when the unit is connected to a network via either Ethernet or modem.
- **Freeze & Sequence** — The icon displays while in the Freeze mode, and the displays while in the Sequence mode.
- **Screen Group** — The number of screen group displays when the DVR is not in the 4x4 display mode of the 16-channel DVR, and 3x3 mode of the 8-channel DVR.
- **Free Space** — The icon displays when the DVR is in the Recycle mode, and the percentage of available storage space displays when the DVR is not in the Recycle mode.
- **Date/Time** — The current date and time information displays.

- **User Name** — The name of the current user logged in displays.
- **Camera No.** — The camera number displays at the top-left corner of each camera screen.
- **Camera Title** — The camera title displays at the top-left corner of each camera screen.
- **Record** — The record related icons display on each camera screen.
- **PTZ** — The icon  displays on each PTZ camera screen.
- **Text-In** — The text input strings display on the screen. You can adjust the Display Dwell time (sec.) for the text input strings displayed on the screen.

You can adjust the transparency of the setup screens by highlighting **Transparency** and using the Left and Right arrow buttons.

Highlighting **OSD Margin...** and pressing the  button displays how OSD text will be displayed on the monitor.



You can adjust the horizontal and vertical margins so that text and icons will not be hidden beyond the edges of the monitor.

Figure 45 — OSD Margin screen.

Highlight the **Main Monitor** tab to switch to the Sequence screen.





Figure 46 — Main Monitor screen.


You can adjust the display dwell time for each camera displayed on the main monitor. Highlight the box beside **Mode** and press the  button. You can select between Full Sequence and Cameo Sequence.



Pressing the **SEQUENCE** button causes the DVR to sequence cameras, and the DVR can sequence cameras in two modes: “Full” and “Cameo”. In the Full mode, the DVR sequences through the cameras and displays them full screen. In the Cameo mode, the bottom right window in a multi-screen format sequences through the cameras.

**NOTE: Any cameras that are Off, have lost video or are set to Covert (unless the user has authority to view covert cameras) will be excluded from the Cameo sequence.**

You can define the screen layout in a variety of formats and set the DVR to sequence through the different screen layouts (pages) so that all the cameras will be displayed. You can also set up the DVR to display one camera or a group of cameras all the time while cycling through the remaining cameras in a “cameo” window. This can be done with one camera displayed full screen while displaying the cameo window as a PIP (picture in picture), or displaying the cameras in a grid pattern with the bottom right window as the cameo.

**NOTE: Sequence cannot be used in the 4x4 display mode of the 16-channel, and 3x3 mode of the 8-channel DVR.**

You can adjust the display dwell time by highlighting the box beside Interval and pressing the  button. You can select dwell intervals ranging from 1 second to 1 minute.

Highlight Event Monitoring On and press the  button. Pressing the  button toggles between On and Off. When it is On, the DVR will display the camera associated with the event when an event occurs.

Highlight the Spot Monitor tab to switch to the Spot Monitor screen.





Figure 47 — Spot Monitor screen.

You can define which cameras display sequentially on the Spot Monitor. Highlight the box in the Channels column and press the  button.

You can save your Display settings by highlighting Save and pressing the  button. Selecting Cancel exits the screen without saving the changes.

## Remote Control Screen


Highlight Remote Control in the Devices menu and press the  button. The Remote Control setup screen allows you to select a port and make correct settings for a remote keyboard.




Figure 48 — Remote Control setup screen.

Highlight the box beside **Port** and select from None, RS232 and RS485. If the RS232 port and RS485 port are in use for PTZ control, networking or text input, the remote keyboard cannot be configured.

Highlight **Setup...** and select the correct Baud Rate, Parity, Data Bits and Stop Bits for the device you are connecting to the DVR.

Highlight the box beside **Remote Control Product** and select the device from the list.

You can save your Remote Control settings by highlighting **Save** and pressing the  button. Selecting **Cancel** exits the screen without saving the changes.


## Recording Settings

Your DVR offers a variety of flexible recording modes. You can set it up to record all the time or to only record events. It can be set up to continue recording once the hard disk drive is full by recording over the oldest video, or you can set it up to alert you when the hard disk is full and stop recording.



Figure 49 — Record menu.

### Record Screen

Highlight **Record** in the Record menu and press the  button. The **Record** setup screen appears.





Figure 50 — Record setup screen.

Highlighting **Recycle** and pressing the  button toggles between On and Off. In the Recycle mode, the DVR records over the oldest video data once all available storage space has been used. When Recycle is turned off, the DVR stops recording once all available storage space has been used.

Highlight the **Resolution** box and select from **High** and **Standard**. All other variables being equal; Selecting High resolution will decrease the recording and playback speed by half that of Standard resolution.

Highlight the **Event Record Dwell** box and set the length of time you would like to record for the associated event. You can set the dwell from 5 seconds to 15 minutes. Refer to *Event Actions* screen in this chapter for information regarding event recording.

Highlight the slide bar beside **Auto Deletion**, and use the Left and Right arrow buttons or Up and Down arrow buttons to adjust the length of time recorded data will be kept from 1 to 999 days. The DVR automatically deletes video recorded earlier than the user-defined period under three conditions: at midnight, whenever the system reboots or whenever the user changes the Auto Deletion settings. Selecting **Never** will disable the Auto Deletion function.

Highlighting **Use Panic Recording** and pressing the  $\odot$  button toggles between On and Off.

Highlight the **Panic Recording – Duration** box and set the duration of panic recording. Panic recording will stop automatically after the preset duration as long as the **PANIC** button is not pressed to stop the panic recording. You can set the dwell from 5 minutes to 1 hour. Select **No Limit** if you want to stop panic recording manually.

Highlighting the **Panic Recording – ips** and pressing the  $\odot$  button allows you to set the images per second for Panic recording. You can select from 0.10 to 30.0 images per second.

Highlighting the **Panic Recording – Quality** and pressing the  $\odot$  button allows you to set the recorded image quality for Panic recording. You can select from: **Very High**, **High**, **Standard** and **Basic**.

You can save your Record settings by highlighting **Save** and pressing the  $\odot$  button. Selecting **Cancel** exits the screen without saving the changes.

## Schedule Screen

Highlight **Schedule** in the Record menu and press the  $\odot$  button, and the Schedule setup screen appears.

**Schedule**

☒ Schedule On

Simple Mode

No.	Day	Range	Mode	Channels	Settings	X
1	All	00:00 ~ 24:00		1~16	...	

+ Default... Save Cancel

Figure 51 — Schedule (Simple Mode) setup screen.









Figure 52 — Schedule (Advanced Mode) setup screen.


You can program the DVR to record only during certain times based on time, day of the week, and holidays. The smallest time segment you can use is 15 minutes.


Highlighting **Schedule On** and pressing the  button toggles between On and Off. In the Schedule On mode, the DVR records video based on the schedule established in the Schedule screen. When turning Schedule recording Off, you will be asked to confirm your decision, and  displays at the top-left corner of each camera screen. Panic recording will function even when Schedule is turned off.  displays during panic recording.

Highlight the **Schedule Mode** box and press the  button. You can select between **Simple Mode** and **Advanced Mode**. Selecting **Advanced Mode** allows you to set up individual recording schedule for each event.



Highlight the **+** and press the  button to add a schedule item.






Highlight the box under the **Day** heading and press the  button to change the days that the scheduled recording will take place. Choose from: Sun, Mon, Tue, Wed, Thu, Fri, Sat, M~F, Hol and All.



Highlight the box under the **Range** heading and press the  button to change the time range that the scheduled recording will take place. The smallest time segment you can use is 15 minutes.


Highlight the box under the **Mode** heading and press the  button to change the recording mode that will be used. Choose from: No Record, Time, Event and Time & Event. (Simple Mode Only)


When the DVR is in the **No Record** mode, it will not record during the preset day and time range as long as the **⏏** button is not pressed. Use the **No Record** mode when you do NOT want the DVR to record during certain times.


When the DVR is in the **Time** mode, the  icon displays at the top-left corner of the screen. The DVR will record and displays the  icon at the top-left corner of the screen during the scheduled times.






When the DVR is in the **Event** mode, the red  icon displays at the top-left corner of the screen. The DVR will record and displays the  icon at the top-left corner of the screen when any event occurs. When the DVR is in the **Pre-Event** recording mode, the yellow  icon displays when there is no event, and the DVR is not recording. When the DVR is in the **Pre-Event** mode, the red  and  display when any event occurs and the DVR starts recording.

When the DVR is in the **Time & Event** mode, the DVR will follow the Time settings and the  icon displays. The DVR follows the Event settings and the  icon displays.

Highlight the box under the **Channels** heading and press the  button to select which cameras will be recorded. (Simple Mode Only)

Highlight the box under the **Settings** heading and press the  button to define the recording settings. You can set the ips and Quality (ips, Quality and Dwell for Advanced Mode setup) of the recording for any modes you set up in the Mode column. If you do not set the ips, Quality and Dwell in the Settings column, the DVR will follow the default settings. See below for details.



+	Type	ips	Quality	Dwell
+	 (1~16)	...	...	...
+	 (1~16)	...	...	...
+	 (1~16)	...	...	...
+	 (1~16)	...	...	...
+	 (1~16)	...	...	...
		...	...	...
		...	...	...
		...	...	...
		...	...	...
		...	...	...

OK Cancel



Figure 53 — Schedule – Settings (Advanced Mode) setup screen.

**NOTE: Descriptions of the Record icons in the *Type* column are as follows:**


 Time-lapse (Time)     Alarm-In     Motion     Video Loss     Text-In

**NOTE: Channels that are not defined will use the setting values of the previous schedule item.**

**NOTE: When multiple events are detected at the same time from a specific channel, the DVR will record event video with the high setting values if the ips, Quality, Resolution and Dwell values of events are different from each other. However, the ips will be reset to the supported maximum value when the ips, Quality, Resolution and Dwell are all set to the highest value. (Advanced Mode Only)**

Highlight the box under the  heading and press the  button to delete the recording settings. You will be asked to confirm that you want to delete the settings.




Highlight Default... and press the  button. The Default screen appears.




Mode	ips	Quality	Dwell
Time	15.00 ips	Standard	5 sec.
Event	30.00 ips	High	5 sec.


← OK Cancel


Figure 54 — Default (Advanced Mode) setup screen.

Highlighting boxes under **ips** and pressing the  button allows you to set the images per second for Time and Event recording. You can select from 0.10 to 30.0 images per second. Highlighting boxes under **Quality** and pressing the  button allows you to set the recorded image quality for Time and Event recording. You can select from: **Very High**, **High**, **Standard** and **Basic**. Highlighting boxes under **Dwell** and pressing the  button allows you to set the length of time you would like to record for the associated event. (Advanced Mode Only)

You can save your changes by highlighting **Save** and pressing the  button. Selecting **Cancel** exits the screen without saving the changes.

## Pre-Event Screen

Highlight **Pre-Event** in the Record menu and press the  button, and the **Pre-Event** setup screen appears. If you do not have Event set up in the Record Schedule, a message will display alerting you to this fact.



No.	ips	Quality	Dwell
<input type="checkbox"/> 1. CAM1	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 2. CAM2	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 3. CAM3	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 4. CAM4	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 5. CAM5	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 6. CAM6	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 7. CAM7	15.00 ips	Standard	00 min. 05 sec.
<input type="checkbox"/> 8. CAM8	15.00 ips	Standard	00 min. 05 sec.


Navigation buttons:  Save Cancel


Figure 55 — Pre-Event setup screen.

When the DVR is in the Event Record mode it is possible to have it record images before the event occurs. The **Pre-Event** screen allows you to define how to handle pre-event recording.

You can turn individual cameras On or Off for pre-event recording. The image speed can be set from 0.10 to 30.00 ips (25.00 ips PAL), and image quality can be selectable from **Very High**, **High**, **Standard** and **Basic**.

You can set the amount of time to record prior to the event by adjusting the **Dwell**. You can set the **Dwell** from 5 seconds to 30 minutes. The longer the dwell set, the fewer maximum ips can be set.

**NOTE: When the DVR is in the Time or Time & Event mode, it ignores the pre-event settings and follows the time settings.**

You can save your changes by highlighting **Save** and pressing the  button. Selecting **Cancel** exits the screen without saving the changes.



## Event Settings

Your DVR can be set to detect many different events. You can also determine how it reacts to these events.




Figure 56 — Event menu.

### Alarm-In Screen

Highlight **Alarm-In** in the Event menu and press the **⏏** button. The **Alarm-In** setup screen appears.

<input type="checkbox"/> No.	Title	Type
<input type="checkbox"/> 1		NC
<input type="checkbox"/> 2		NC
<input type="checkbox"/> 3		NC
<input type="checkbox"/> 4		NC
<input type="checkbox"/> 5		NC
<input type="checkbox"/> 6		NC
<input type="checkbox"/> 7		NC
<input type="checkbox"/> 8		NC

Panic Record: None

Figure 57 — Alarm-In Settings screen.

The alarm terminal strip on the back of the DVR has inputs associated with each alarm. You can set up each input on the **Alarm-In** screen. You can turn each input On or Off by highlighting the alarm number and pressing the **⏏** button.

Each input can be given a title. Highlight the desired Title box and press the **⏏** button. A virtual keyboard appears allowing you to enter a title name.

Each input can be set as **NO** (normally open) or **NC** (normally closed).

You can set up the DVR to start panic recording whenever it senses an input on one of its alarm input connectors. Highlight the box beside **Panic Record** and press the **⏏** button. A list of Alarm Inputs appears, and you can select which alarm input you want associated with panic recording. The DVR will continue panic recording until an input on the selected alarm input is released as long as the **PANIC** button is not pressed to stop the panic recording.

Highlight the **Actions 1** and **Actions 2** tabs, and the Actions 1 and Actions 2 setup screens appear.

No.	Record	Alarm-Out	Notify
1	1	Beep	
2	2	Beep	
3	3	Beep	
4	4	Beep	
5	5	Beep	
6	6	Beep	
7	7	Beep	
8	8	Beep	

Figure 58 — Alarm-In Actions 1 screen.

You can set the actions the DVR will take whenever it senses an input on one of its alarm input connectors.

Highlight the desired box under the **Record** heading, and press the button. A list of cameras appears. Select the cameras that you want the DVR to record whenever it detects an input on the associated alarm input.

**NOTE: For the Record action, the camera you select should be set to the Event or Time & Event recording mode in the Record Schedule setup screen.**

Highlight the desired box under the **Alarm-Out** heading, and press the button. A list of Alarm Outputs and Beep appear. Select the Alarm Output connectors that you would like to activate whenever the DVR detects an input on the associated alarm input. You can also set the DVR's internal buzzer to sound.

**NOTE: For the Alarm-Out action, the alarm output and beep you select should be set to the Event mode in the Alarm-Out setup screen (Schedule tab).**

Highlight the desired box under the **Notify** heading, and press the button. The Alarm-In Notify menu appears.

You can toggle the entire list On and Off by highlighting Notification and pressing the button. You can toggle the individual items On and Off by highlighting that item and pressing the button. Highlight OK and press the button to accept your changes.

**NOTE: For the Notify action, the notify item you select should be enabled in the Notification setup screen and the DVR should be registered in the RAS (Remote Administration System).**

Figure 59 — Alarm-In Notify menu.

**NOTE: The DVR will also log and notify when an input is released during an alarm (Alarm-In Off event).**

No.	PTZ	Spot Monitor
1		
2		
3		
4		
5		
6		
7		
8		

Figure 60 — Alarm-In Actions 2 screen.

Highlight the desired box under the **PTZ** heading, and press the button. A list of PTZ presets appear. Select the preset position for each PTZ camera, where you want PTZ cameras to move to whenever the DVR detects an input on the associated alarm input.

Highlight the desired box under the **Spot Monitor** heading, and press the button. A list of a SPOT monitor and cameras appears. A SPOT monitor can be associated with a camera. The DVR will display the associated camera on the SPOT monitor whenever it detects an input on the associated alarm input.

You can save your Alarm-In changes by highlighting **Save** and pressing the button. Selecting **Cancel** exits the screen without saving the changes.

## Motion Detection Screen

Highlight Motion Detection in the Event menu and press the button. The Motion Detection setup screen appears.


No.	Sensitivity	Zone	Min. Blocks	Zone View
1	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
2	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
3	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
4	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
5	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
6	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
7	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>
8	3 / 3	192 Block(s)	1 / 1	<input type="checkbox"/>

Motion Ignoring Interval: 2 sec. Daytime Setup...

Figure 61 — Motion Detection Settings screen.

Your DVR has built-in video motion detection. Video motion detection can be turned On or Off for each camera.

Highlighting the box under the **Sensitivity** heading and pressing the button allows you to adjust the DVR's sensitivity to motion for Daytime and Nighttime independently.



There are five settings with 1 being the least sensitive and 5 being the most sensitive.

Figure 62 — Motion Detection Sensitivity screen.

You can adjust the minimum number of detection blocks that must be activated to trigger a motion alarm. Highlighting the box under the **Min. Blocks** heading and pressing the  $\odot$  button allow you to adjust the minimum number of detection blocks for Daytime and Nighttime independently.




Smaller numbers provide greater sensitivity because fewer detection blocks must be activated.

Figure 63 — Motion Detection Min. Blocks screen.

Turning **Zone View On** will allow you to observe how the DVR is reacting to motion. When in the motion viewing mode, any detected motion within the zone will be displayed in red.

You can define the area of the image where you want to detect motion; e.g., a doorway. Highlight the box under the **Zone** heading, and press the  $\odot$  button. The **Motion Detection Zone** screen displays.




The **Motion Detection Zone** screen is laid over the video for the selected camera. You can set up motion detection zones by selecting or clearing blocks.

**NOTE: You can set up motion zones one block at a time in groups of 8 or 16 individual block groups (8- and 16-channel DVR respectively). A block group is positioned within the image area using the Up and Down arrow buttons, and individual blocks within the block groups are selected or cleared using the camera buttons.**

Figure 64 — Motion Detection Zone screen.

Press the  $\odot$  button to display the menu screen. The menu on the setup screen has the following functions:





**Select** — Activates highlighted blocks to detect motion.  
**Clear** — Deactivates highlighted blocks so that they will not detect motion.  
**Reverse** — Activates inactive highlighted blocks and deactivates active highlighted blocks.  
**Select All** — Activates all blocks to detect motion.  
**Clear All** — Deactivates all blocks so that they will not detect motion.  
**Reverse All** — Activates inactive blocks and deactivates active blocks.  
**OK** — Accepts changes and closes Zone setup.  
**Cancel** — Exits Zone setup without saving changes.

Figure 65 — Motion Detection Zone menu.

You can control excessive event logging and remote notification of motions detected after the motion dwell time by adjusting the motion ignoring dwell intervals. Highlight the box beside **Motion Ignoring Interval** and press the  $\odot$  button. A list of intervals ranging from 1 to 10 seconds or **Never** appears. The DVR will not log and notify motion events occurred during the preset interval range.

**NOTE: The record action for motion events will not be affected by the Motion Ignoring function.**

Highlighting the box beside **Daytime Setup** and pressing the  button allow you to set up the Daytime range.



Daytime Setup

Daytime 09:00 ~ 18:00

OK Cancel



Highlight the box beside **Daytime** and press the  button. Use the Up and Down arrow buttons to set the Daytime range. The DVR will consider the remaining time range as the Nighttime.

Figure 66 — Daytime Setup screen.

Highlight the **Actions 1** and **Actions 2** tabs and the Motion Detection Actions 1 and Actions 2 screens display.



Motion Detection

Settings Actions 1 Actions 2


No.	Record	Alarm-Out	Notify
1	1~16	Beep	
2	1~16	Beep	
3	1~16	Beep	
4	1~16	Beep	
5	1~16	Beep	
6	1~16	Beep	
7	1~16	Beep	
8	1~16	Beep	

Save Cancel


Figure 67 — Motion Detection Actions 1 screen.

The DVR can be set to react to motion detection differently for each camera. Each camera can be associated with another camera, trigger an Alarm-Out connector, sound the DVR's internal buzzer, notify a number of different devices, move PTZ cameras to preset positions, and/or display a camera on a SPOT monitor.





**NOTE: You can associate multiple cameras with a camera that detects motion.**

Highlight the box under the **Record** heading and press the  button. A list of cameras appears. You can associate as many cameras with that camera as you wish. If the DVR detects motion on the selected camera, it starts recording video from all the associated cameras.


**NOTE: For the Record action, the camera you select should be set to the Event or Time & Event recording mode in the Record Schedule setup screen.**

Highlight the box under the **Alarm-Out** heading and press the  button. A list of Alarm Outputs appears. You can associate Alarm-Outs with that camera as you wish. When the DVR detects motion on the selected camera's input, it triggers output signals on the associated Alarm-Out connectors. You can also have the DVR's internal buzzer sound if motion is detected on the selected camera.

**NOTE: For the Alarm-Out action, the alarm output and beep you select should be set to the Event mode in the Alarm-Out setup screen (Schedule tab).**

Highlight the box under the **Notify** heading and press the  button. You can toggle the entire list On and Off by highlighting **Notification** and pressing the  button. You can toggle the individual items On and Off by highlighting that item and pressing the  button. Highlight OK and press the  button to accept your changes.

**NOTE:** For the Notify action, the notify item you select should be enabled in the Notification setup screen and the DVR should be registered in the RAS (Remote Administration System).





The screenshot shows the 'Motion Detection' configuration window with the 'Actions 2' tab selected. It contains a table with 8 rows for configuring PTZ and Spot Monitor actions.


No.	PTZ	Spot Monitor
1		
2		
3		
4		
5		
6		
7		
8		

At the bottom, there is a back arrow button, a 'Save' button, and a 'Cancel' button.


Figure 68 — Motion Detection Actions 2 screen.


Highlight the desired box under the **PTZ** heading, and press the  button. A list of PTZ presets appear. Select the preset position for each PTZ camera, where you want PTZ cameras to move to whenever the DVR detects motion on the selected camera's input.

Highlight the desired box under the **Spot Monitor** heading, and press the  button. A list of a SPOT monitor and cameras appears. A SPOT monitor can be associated with a camera. The DVR will display the associated camera on the SPOT monitor whenever it detects motions on the selected camera.

You can save your Motion Detection changes by highlighting **Save** and pressing the  button. Selecting **Cancel** exits the screen without saving the changes.

## Video Loss Screen

Highlight **Video Loss** in the Event menu and press the  button. The **Video Loss** setup screen appears.



The screenshot shows the 'Video Loss' configuration window with the 'Settings' tab selected. It contains two settings with sliders.

Video Loss Interval	<input type="checkbox"/>	Don't Use
Check Obscuration	<input type="checkbox"/>	Never

At the bottom, there is a back arrow button, a 'Save' button, and a 'Cancel' button.

Figure 69 — Video Loss Settings screen.

Highlight the slide bar beside **Video Loss Interval**, and use the Left and Right arrow buttons to adjust the settings. A list of intervals for video loss detection ranging from 0.1 to 15 seconds or **Don't Use** appears. When any cameras have lost video and it lasts for the preset interval range, the DVR will consider it as video loss.

The DVR checks to see if anything is obscuring the camera. Highlight the slider bar beside **Check Obscuration**, and use the Left and Right arrow buttons to adjust the setting. The sensitivity can be set from **Never** to 15 (extremely sensitive).

Highlight the **Actions 1** and **Actions 2** tabs and the **Video Loss Actions 1** and **Actions 2** screens display.

No.	Record	Alarm-Out	Notify
1		Beep	
2		Beep	
3		Beep	
4		Beep	
5		Beep	
6		Beep	
7		Beep	
8		Beep	

Figure 70 — Video Loss Actions 1 screen.

The DVR can be set to react to video loss differently for each camera. Each camera can be associated with another camera, trigger an Alarm-Out connector, sound the DVR's internal buzzer, notify a number of different devices, move PTZ cameras to preset positions, and/or display a camera on a SPOT monitor.

Highlight the box under the **Record** heading and press the button. A list of cameras appears. You can associate as many cameras with that camera as you wish. If the DVR detects video loss on the selected camera, it starts recording video from all the associated cameras.

**NOTE: For the Record action, the camera you select should be set to the Event or Time & Event recording mode in the Record Schedule setup screen.**

Highlight the box under the **Alarm-Out** heading and press the button. A list of Alarm Outputs appears. You can associate Alarm-Outs with that camera as you wish. When the DVR detects video loss on the selected camera, it will trigger output signals on the associated Alarm-Out connectors. You can also have the DVR's internal buzzer sound if video is lost on the selected camera.

**NOTE: For the Alarm-Out action, the alarm output and beep you select should be set to the Event mode in the Alarm-Out setup screen (Schedule tab).**

Highlight the box under the **Notify** heading and press the button. You can toggle the entire list On and Off by highlighting **Notification** and pressing the button. You can toggle the individual items On and Off by highlighting that item and pressing the button. Highlight **OK** and press the button to accept your changes.

**NOTE: For the Notify action, the notify item you select should be enabled in the Notification setup screen and the DVR should be registered in the RAS (Remote Administration System).**

**NOTE: The DVR will also log and notify when detecting video again after video loss (Video Loss Off event).**

No.	PTZ	Spot Monitor
1	...	...
2	...	...
3	...	...
4	...	...
5	...	...
6	...	...
7	...	...
8	...	...

Figure 71 — Video Loss Actions 2 screen.

Highlight the desired box under the **PTZ** heading, and press the button. A list of PTZ presets appear. Select the preset position for each PTZ camera, where you want PTZ cameras to move to when the DVR detects video loss on the selected camera's input.

Highlight the box under the **Spot Monitor** heading and press the button. A list of a SPOT monitor and cameras appears. A SPOT monitor can be associated with a camera. The DVR will display the associated camera on the SPOT monitor whenever it detects video loss on the selected camera.

You can save your Video Loss changes by highlighting **Save** and pressing the button. Selecting **Cancel** exits the screen without saving the changes.

## Text-In Screen


Highlight **Text-In** in the Event menu and press the button. The **Text-In** setup screen appears.

No.	Setup	Title
1	...	...
2	...	...
3	...	...
4	...	...
5	...	...
6	...	...
7	...	...
8	...	...


Figure 72 — Text-In Settings screen.

The DVR can be set to react to text input from devices such as ATMs (Automated Teller Machines) and POS (Point of Sale; i.e., cash registers). This screen allows you to configure the DVR for each text-in device.




Highlight the box under the **Setup** heading, and press the  button. Selecting the **Setup** heading changes all the parameters excluding Port settings of all the text input channels.

**NOTE: The system performance might be affected when a large quantity of text inputs are detected from several channels at the same time.**




The image shows a 'Text-In 1' settings window. At the top, there's a 'Port' dropdown menu set to 'None' and a 'Setup...' button. Below that is 'Text-In Product' set to 'Generic Text'. The main area contains several input fields: 'Transaction Start', 'Transaction End', 'Line Delimiter', and 'Ignore String'. To the right of these is a checkbox for 'Any Character' (unchecked) and a dropdown for '0 more line(s)'. Below the input fields are checkboxes for 'Case Sensitive' (unchecked) and a 'Time Out' field set to '10 min. 00 sec.'. At the bottom right are 'OK' and 'Cancel' buttons.

Figure 73 — Text-In Device Settings screen.

Highlight the box beside **Port**, and press the  button. Select from None, RS232, RS485 and USB-Serial (1~8).


**NOTE: If you have set the Port as *None*, you will not be able to make any changes to the screen.**


**NOTE: When using the USB to serial text-in device, do NOT remove the USB cable from the port while the system is running.**

Highlight **Setup...**, and press the  button. Use the ATM or POS manufacturer's recommended settings when configuring the RS232, RS485 or USB-Serial ports.


Highlight the box beside **Text-In Product**, and press the  button. Select your device from the list.


**NOTE: The following description is for a *Generic Text Device*. The screen changes for different types of text input devices, and there will be different parameter boxes for you to enter information.**


Highlight the box beside **Transaction Start**, and press the  button. Use the virtual keyboard to enter the Transaction Start string. Refer to the device manufacturer's documentation for the text string that the device first sends when a transaction starts.


If you want the DVR to react to any character sent from the text input device, you will want to turn On **Any Character**. Highlight **Any Character**, and press the  button to toggle between On and Off.


**NOTE: If *Any Character* is turned On, you will not be able to enter any text in the *Transaction Start* box.**


Highlight the box beside **Transaction End**, and press the  button. Use the virtual keyboard to enter the Transaction End string. Refer to the device manufacturer's documentation for the text string that the device sends when a transaction ends.

Highlight the **more line(s)** box, and press the  button. Select the number of additional lines of text that you want the DVR to record. You can choose from 0 to 10.


Highlight the box beside **Line Delimiter**, and press the  button. Use the virtual keyboard to enter the character(s) that the device uses to indicate the end of a line. Special characters can be created using ^ and a capital letter; e.g., ^J for NL (New Line), ^M for CR (Carriage Return). Refer to the device manufacturer's documentation for Line Delimiter character(s).

Highlight the box beside **Ignore String**, and press the  button. Use the virtual keyboard to enter any strings of text that you want the DVR to ignore. Refer to the device manufacturer's documentation for text strings that the device sends during transactions, so you will know which ones you do not want recorded.

Highlight the **Case Sensitive** box, and press the  button to toggle between On and Off. Refer to the device manufacturer's documentation to determine if the text strings are Case Sensitive. If the device distinguishes between upper and lower case letters, make certain the **Case Sensitive** box is turned On.

Highlight the box beside **Time Out**, and press the  button. Set the length of time to wait for the new text string. The DVR will consider a transaction complete if no new text strings are entered between the last text input and the dwell time out. You can adjust the Time Out dwell from 5 seconds to 15 minutes.


Highlight the **Actions 1** and **Actions 2** tabs and the **Text-In Actions 1** and **Actions 2** screens display.




No.	Record	Alarm-Out	Notify
1		Beep	
2		Beep	
3		Beep	
4		Beep	
5		Beep	
6		Beep	
7		Beep	
8		Beep	

Figure 74 — Text-In Actions 1 screen.





The DVR can be set to react to text input. Text input can be associated with cameras, trigger an Alarm-Out connector, sound the DVR's internal buzzer, notify a number of different devices, move PTZ cameras to preset positions, and/or display a camera on a SPOT monitor.

Highlight the box beside **Record** and press the  button. A list of cameras appears. You can associate as many cameras with the Text Input as you wish. If the DVR detects text input, it starts recording video from all the associated cameras.


**NOTE: For the Record action, the camera you select should be set to the Event or Time & Event recording mode in the Record Schedule setup screen.**

Highlight the box beside **Alarm-Out** and press the  button. A list of Alarm Outputs appears. You can associate Alarm-Outs with the Text Input as you wish. When the DVR detects text input, it triggers output signals on the associated Alarm-Out connectors. You can also have the DVR's internal buzzer sound if text input is detected.

**NOTE: For the Alarm-Out action, the alarm output and beep you select should be set to the Event mode in the Alarm-Out setup screen (Schedule tab).**

Highlight the box beside **Notify** and press the  button. You can toggle the entire list On and Off by highlighting **Notification** and pressing the  button. You can toggle the individual items On and Off by highlighting that item and pressing the  button. Highlight **OK** and press the  button to accept your changes.


**NOTE: For the Notify action, the notify item you select should be enabled in the Notification setup screen and the DVR should be registered in the RAS (Remote Administration System).**




The screenshot shows the 'Text-In' configuration screen with the 'Actions 2' tab selected. It contains a table with 8 rows and 3 columns: 'No.', 'PTZ', and 'Spot Monitor'. Each row has a small '...' button next to the 'PTZ' and 'Spot Monitor' headers. At the bottom, there are 'Save' and 'Cancel' buttons.

No.	PTZ	Spot Monitor
1	...	...
2	...	...
3	...	...
4	...	...
5	...	...
6	...	...
7	...	...
8	...	...


Figure 75 — Text-In Actions 2 screen.


Highlight the desired box under the **PTZ** heading, and press the  button. A list of PTZ presets appear. Select the preset positions for each PTZ camera, where you want PTZ cameras to move to when the DVR detects text input.

Highlight the box beside **Spot Monitor** and press the  button. A list of a SPOT monitor and cameras appears. A SPOT monitor can be associated with a camera. The DVR will display the associated camera on the SPOT monitor whenever it detects an input on the selected text-in device.

You can save your Text-In changes by highlighting **Save** and pressing the  button. Selecting **Cancel** exits the screen without saving the changes.

## System Event Screen

Highlight **System Event** in the Event menu and press the  button. The System Event setup screen appears.



The screenshot shows the 'System Event' configuration screen with the 'Health Check' tab selected. It includes a 'System' dropdown menu set to 'Never', a 'Check Recording' button labeled 'Setup...', and a table for 'Check Alarm-In' and 'Interval' settings. At the bottom, there are 'Save' and 'Cancel' buttons.

Check Alarm-In	Interval
Alarm-In 1	Never
Alarm-In 2	Never
Alarm-In 3	Never
Alarm-In 4	Never

Figure 76 — Health Check screen.

The DVR can be configured to run self-diagnostics and report the results.

Highlighting the box beside **System** and pressing the  $\odot$  button allows you to select the interval that you want the DVR to run self-diagnostics on the system. You can select from 1 hr. to 30 days or **Never**.

Highlight the **Setup...** box beside **Check Recording** and press the  $\odot$  button. The Check Recording screen appears.

No.	Day	Range	Interval	X
1	All	00:00 ~ 24:00	1 min.	X
				X
				X
				X
				X
				X
				X
				X
				X
				X

OK Cancel

Highlighting **Schedule On** and pressing the  $\odot$  button toggles On and Off. When set to On, you can select the day, time range and interval that you want the DVR to run self-diagnostics on the recorder. The **Interval** can be selectable from 1 min. to 7 days or **Never**. The **X** box allows you to delete a check recording schedule.

Figure 77 — Check Recording screen.

Highlighting the box under the **Interval** heading beside each alarm-in and pressing the  $\odot$  button allows you to change the interval that you want the DVR to run self-diagnostics on Alarm Inputs. You can select from 1 hr. to 30 days or **Never**.

Highlight the **Storage** tab and the Storage screen displays.

System Event

Health Check Storage Actions

Disk Bad Notify 50%

Disk Almost Full Notify 90%

Disk S.M.A.R.T. Setup...

Save Cancel

Figure 78 — Storage screen.

Highlight the box beside **Disk Bad Notify**, and press the  $\odot$  button. Select percentage level of bad disk sectors at which you want the DVR to trigger an alert. Percentage levels range from 10% to 90%.

Highlight the box beside **Disk Almost Full Notify**, and press the  $\odot$  button. Select the percentage level of disk usage at which you want the DVR to trigger an alert. Percentage levels range from 80% to 99%.

Highlight the **Setup...** box beside **Disk S.M.A.R.T.**, and press the  $\odot$  button. The S.M.A.R.T. Setup screen appears.

**S.M.A.R.T. Setup**

☒ Enable

Check Time: Daily 00:00

Temperature Threshold: 70 °C

Last Check-Time: 08/28/2007 11:43

Navigation buttons: Back, OK, Cancel

Figure 79 — S.M.A.R.T. Setup screen.

Highlight **Enable**, and press the  $\odot$  button to toggle between On and Off.

**NOTE:** If **Enable** is turned Off, you will not be able to make changes to any of the boxes.

Highlight the box beside **Check Time**, and press the  $\odot$  button. You can select from **Monthly**, **Weekly** and **Daily**. If you select **Monthly**, you will be asked to set the Day of the Month and Time. If you select **Weekly**, you will be asked to set the Day of the Week and Time. If you select **Daily**, you will be asked to set the Time.

Highlight the first box beside **Temperature Threshold**, and press the  $\odot$  button. Use the Up and Down arrow buttons to scroll through the numbers. Refer to the hard disk drive manufacturer's documentation for the correct temperature setting. If the temperature of hard disk drive exceeds the defined threshold, the system triggers an alert.

Highlight the second box beside **Temperature Threshold**, and press the  $\odot$  button. Select either °C (Celsius) or °F (Fahrenheit), and press the  $\odot$  button.

The box beside **Last Check-Time** displays the Date and Time of the last S.M.A.R.T. check.

Highlight **OK**, and press the  $\odot$  button to accept the changes. Selecting **Cancel** exits the screen without saving the changes.

Highlight the **Actions** tab and the System Event Actions screen displays.

**System Event**


Health Check | Storage | **Actions**

Event	Alarm-Out	Notify
System	...	...
Panic Record	...	...
Check Recording	Beep	...
Check Alarm-In	Beep	...
Disk Almost Full	Beep	...
Disk Full	Beep	...
Disk Bad	Beep	...
Disk Temperature	Beep	...





Navigation buttons: Back, Save, Cancel

Figure 80 — System Event Actions screen.

The DVR can be set to react to system events. System events can be associated with an Alarm-Out connector, sound the DVR's internal buzzer, and/or notify a number of different devices.

Highlight the Alarm-Out box beside the desired event (Check Recording, Check Alarm-In, Disk Almost Full, Disk Full, Disk Bad, Disk Temperature, or Disk S.M.A.R.T.), and press the  button. A list of Alarm Outputs appears. You can associate as many Alarm-Outs with the Event as you wish. If the DVR detects that event, it triggers output signals on all the associated Alarm-Out connectors. You can also have the DVR's internal buzzer sound if an event is detected.

**NOTE:** *Alarm-Out* action cannot be set to *System* and *Panic Record* events.

Highlight the Notify box beside the desired event (System, Panic Record, Check Recording, Check Alarm-In, Disk Almost Full, Disk Full, Disk Bad, Disk Temperature, or Disk S.M.A.R.T.), and press the  button. You can toggle the entire list On and Off by highlighting Notification and pressing the  button. You can toggle the individual items On and Off by highlighting that item and pressing the  button. Highlight OK and press the  button to accept your changes.


**NOTE:** *Mail* notify is the only option available for the *System* event.

**NOTE:** For the Notify action to work, the DVR should be registered in the RAS (Remote Administration System).

You can save your System Event changes by highlighting Save and pressing the  button. Selecting Cancel exits the screen without saving the changes.

## Event Status Screen

Highlight Event Status in the Event menu and press the  button. The Event Status screen appears.



Event Status																
Event Status    Storage																
Alarm-In	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Check Alarm-In	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Motion	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Video Loss	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Text-In	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Panic Record																
Check Recording																
Disk Almost Full																
Disk Full																
																Close

Figure 81 — Event Status screen.

The Event Status screen displays the status of the DVR's systems and inputs. Events will be highlighted, and related channels or events will flicker for five seconds when detected.

Alarm-In, Motion, Video Loss and Text-In will be highlighted when each event is detected based on the settings you made in the Alarm-In, Motion Detection and Text-In setup screen on the Event menu.

Check Alarm-In and Check Recording will be highlighted when each event is detected based on the settings you made in the System Event setup screen on the Event menu.

Panic Record will be highlighted while the DVR is in the panic recording mode.

Disk Almost Full will be highlighted when the DVR is not in the Recycle mode and the level of disk usage reaches the Disk Almost Full percentage you made in the System Event setup screen on the Event menu. Disk Full will be highlighted when the DVR is not in the Recycle mode and all available storage space has been used.

Highlighting the Storage tab will display the hard disk drive status. Refer to the Storage Screen section for details.





## Chapter 4 — Operation

**NOTE:** This chapter assumes your DVR has been installed and configured. If it has not, please refer to Chapters 2 and 3.

The DVR's controls are similar to a VCR. As with a VCR, the main functions are recording and playing back video. However, you have much greater control over recording and playing back video. You can establish recording schedules based on time of day and day of the week. The DVR allows you to search through the recorded video using much more sophisticated tools than those available with VCRs. Additional DVR features that are not available with VCRs are remote control and viewing, and recording video at the same time you are watching previously recorded video.

The front panel controls are described in *Chapter 3 — Configuration*.

### Turning on the Power

Once you have installed the DVR following the instructions in *Chapter 2 — Installation*, it is ready to record.

### Live Monitoring

As soon as the DVR completes its initialization process, it will begin showing live video on the attached monitor and playing live audio through the attached speaker. The default mode is to display all cameras at once. Pressing any camera button will cause that camera to display full screen. It displays live video and plays live audio until the user enters another mode.


Pressing the **DISPLAY** button cycles the DVR through the different display formats.

The DVR can be set to display full-screen video for a preset dwell time when an Event occurs. Video from the lowest camera number associated with the event sensor will be displayed, the DVR will return to the previous screen format after event monitoring dwell time expires. While the event monitoring is activated, the monitoring for all other subsequent events will be ignored. Pressing individual camera buttons or the **DISPLAY** button during event monitoring releases the current event monitoring and displays the selected camera or returns to the previous screen format.

### PIP Mode



You can display a Picture-in-Picture by pressing the **DISPLAY** button in the single-screen mode. You can change the location of the PIP counterclockwise and clockwise by pressing the Up and Down arrow buttons and change its size by pressing the Left and Right arrow buttons.

### Active Cameo Mode



You can enter the Active Cameo mode by pressing and holding the **CAMEO** button for two seconds or longer in any multi-view format or selecting **Group Edit** in the Mouse display menu. The yellow outline surrounding the video indicates the active cameo, and pressing the arrow buttons moves the active cameo. Pressing the  (Play/Pause) button exits the Active Cameo mode. Selecting **Exit Group Edit** in the cameo menu displayed when pressing the **CAMEO** button also exits the Active Cameo mode. The active cameo mode will remain in effect for 15 seconds if there is no further operation.

In active cameo mode, press the button for the camera you want to display in the active cameo. After setting the camera number to active cameo, the DVR moves the active cameo to the next cameo. When the camera number exists on the current screen, the active cameo is changed with the existing camera number. When the camera number does not exist on the current screen, the active cameo is replaced by the camera number. You can change the screen layout in this way.

## Freeze Mode

Pressing the  (Play/Pause) button will freeze the current image on the screen until you press the button again. While in the Freeze mode, the icon  displays in bottom-left corner if Freeze is selected in the Display setup screen (OSD tab).

## Zoom Mode

You can enlarge an area of the video by pressing the **Zoom** button. For a few seconds after pressing the **Zoom** button, a rectangle displays on the screen. A rectangle shows the area that will be enlarged. You can move the rectangle around using the arrow buttons. Pressing the  (Play/Pause) button in the Zoom mode enlarges the area in rectangle. Exit the Zoom mode by pressing the **Zoom** button. While in the Zoom mode, the icon  displays if Zoom is selected in the Display setup screen (OSD tab).

## Image Adjustment


**NOTE: It is important that cameras and monitors are correctly installed and adjusted prior to making any image adjustments using the DVR's controls.**

If a user who has Color Control authority logs into the system, the user can adjust the image. Pressing and holding a camera button for a few seconds displays an image adjustment dialog. You can control brightness, contrast, hue and saturation for each camera.

**NOTE: Any image adjustments you make will be applied to both the live video on the monitors and the recorded video.**

## Sequence Mode

Pressing and holding the **SEQUENCE** button for two seconds or longer causes the cameras to display sequentially. When in one of the multi-view formats, pressing this button will cause the DVR to go through predefined screen layouts (Full Sequence). Or, the bottom, right screen will display live cameras sequentially (Cameo Sequence). Pressing the **SEQUENCE** button again for two seconds or longer exits the Sequence mode. When in one of the multi-view formats, pressing the **SEQUENCE** button will cause the DVR to go to the next page. For example, if you press the **SEQUENCE** button in the 2x2 format, the DVR changes pages as follows:



If all the cameras in a page are Off, have lost video or are set to Covert (unless the user has authority to view covert cameras), that page will be excluded from the sequence.

**NOTE: The *Full Sequence* for the full sequence monitoring and the *Cameo Sequence* for the cameo sequence monitoring should be selected in the Display setup screen (Sequence tab).**

## Event Monitoring

When an event occurs, the DVR will display the camera associated with the event if Event Monitoring On is selected in the Display setup screen (OSD tab).

How the cameras are displayed depends on the number of cameras associated with the event. If one camera is associated with the event, the DVR will display the camera full screen. If two to four cameras are associated with the event, the DVR will display the cameras on a 2x2 screen. If five to nine cameras are associated with the event, the DVR will display the cameras on a 3x3 screen. If 10 or more cameras are associated with the event, the DVR will display the cameras on a 4x4 screen.

Event monitoring lasts for the dwell time set for event recording. After the dwell time has elapsed, the monitor returns to the previous screen unless another event has occurred. If you want to return to the live monitoring mode before the dwell time has elapsed, press the **DISPLAY** button or one of the camera buttons.

## Covert Camera

If a camera is set up as Covert 1 in the Camera setup screen (Settings tab), that camera will not be displayed unless a user with Covert Camera View authority logs into the system. However the camera title and status icons will be displayed on the monitor.


If a camera is set up as Covert 2 in the Camera setup screen (Settings tab), that camera appears to be Off unless a user with Covert Camera View authority logs into the system. The camera title will be grayed out and status icons will not be displayed on the monitor.

**NOTE: When a camera is set up as Covert 1, the DVR displays the camera title and status icons on the covert video. When set up as Covert 2, the DVR displays only the camera title on the covert video.**

If a user who has Covert Camera View authority logs into the system, the user can view video from cameras set to Covert 1 or Covert 2 including the camera titles and status icons.

## Spot Monitoring

You can select the camera you want to display on a Spot Monitor. Press and hold the **SPOT** button on the front panel for two seconds or longer displays the Sequence Menu.




Select the camera to be displayed on the Spot Monitor. Selecting **Sequence** from the menu displays more than one camera on a Spot Monitor sequentially. Select **Sequence** again to stop sequencing on the Spot Monitor. Any cameras that are Off, have lost video or are set to Covert (unless the user has authority to view covert cameras) will be excluded from the sequence. When the Spot Monitor is in the sequence mode, you can set the camera's display dwell time. Refer to *Chapter 3 – Configuration – Display Screen* section for details.

Figure 82 — Sequence menu.

# PTZ Mode


If a user who has **PTZ Control** authority logs into the system, the user can control PTZ cameras. The DVR will control cameras with Pan, Tilt and Zoom capabilities. Press and hold the **PTZ** button for two seconds or longer to display the PTZ camera menu and enter the PTZ mode, and press the button again to exit the PTZ mode.



Select the PTZ camera you wish to control. The icon **PTZ** flickers on the PTZ camera screen. You can control the camera using front panel control buttons, by setting up presets or by selecting the expanded PTZ features. To use the front panel buttons, press the Left and Right arrow buttons to pan left and right. Press the Up and Down arrow buttons to tilt the camera up and down. Press the camera button 1 to zoom in, and press the button 2 to zoom out. You can use the button 3 and button 4 to focus the image. You can establish preset positions for PTZ cameras. Press the camera button 6 to establish Presets. You can quickly move PTZ cameras to Preset positions. Press the camera button 5 to view an establish camera Preset position.


Figure 83 – PTZ Select Camera menu.

You can save camera position settings as “presets” so that you can go directly to desired views.



Once you have the camera at the desired settings, press the **PTZ** button, and the PTZ Preset dialog box will appear. Select the number you want to assign to the preset and press the **PTZ** (Play/Pause) button. Use the virtual keyboard to enter the preset name.

Figure 84 – PTZ Preset screen.



Press the **PTZ** button to load the PTZ preset and the Preset View dialog box will appear. Select the desired preset and press the **PTZ** button to load the preset.

Figure 85 – Preset View screen.


Pressing the **MENU** button displays the following PTZ menu.



Set the feature you wish to control by selecting it from the menu. Refer to the camera manufacturer's instructions for the proper settings. Depending on the camera specifications, some features may not be supported.

Figure 86 – PTZ menu.


You can use a mouse for convenient PTZ control. Position the mouse pointer at the bottom of the screen, and the following PTZ toolbar will display.



Zoom In / Out  
Iris Open / Close



Focus Near / Far  
Set / Load Preset

Clicking  on the left side exits the toolbar. If you want to display the toolbar again, position the mouse pointer at the bottom of the screen. Change the toolbar location by clicking the empty space on the left side of the toolbar and drag it to where you want it located on the screen. Use the arrow buttons on the toolbar to pan or tilt the camera in the direction you want.


## Using a Mouse


You can use a mouse instead of the front panel buttons to perform many of the DVR functions. The following operations are supported when using a mouse during live monitoring.

When in one of the multi-view formats (e.g., PIP, 2x2, 3x3 or 4x4), clicking the mouse button on a camera image switches that camera to full screen. Clicking the mouse button again returns to the previous multi-view format.

When in one of the multi-view formats, scrolling the mouse wheel up and down operates the same as pressing the **DISPLAY** button by switching the screen format between PIP, 2x2, 3x3 and 4x4.

Clicking the right mouse button during live monitoring displays the following menu:




Selecting **Freeze**, **PTZ...** and **Spot Monitor...** is the same as pressing the  (Play/Pause), **PTZ** and **SPOT** buttons for two seconds or longer as described above in the *Live Monitoring* section of this chapter.

Selecting **Zoom...** zooms in on the live image. While in the zoom mode, there are two ways to move around the enlarged portion of the video. First, there is a rectangle showing what area of the image will be enlarged. Click inside the rectangle to move to another area of the image you want enlarged. Second, click and hold the mouse button on the enlarged video and drag the video.

Figure 87 — Mouse menu.

Selecting **Display** shows the following menu:



Clicking **Camera** and selecting the camera number is the same as pressing the individual camera buttons on the front panel which displays the selected camera full screen. When in the PIP display mode, clicking the right mouse button and selecting PIP changes the location and the size of the PIP.

Selecting PIP, 2x2, 3x3 and 4x4 display the cameras in the selected multi-view screen mode. Clicking **Previous Group** moves to the previous page. Clicking **Next Group** is the same as pressing the **GROUP** button on the front panel which moves to the next page.

Selecting **Edit Group** supports the active cameo function. Select **Edit Group** and choose a camera that you want to change display position (e.g., Camera A). Then, click the right mouse button to display the menu. If you select another camera in the menu (e.g., Camera B), the screen displays Camera B instead of Camera A. When in the 4x4 format, Camera A and Camera B will switch positions.

Figure 88 — Mouse Display menu.

## Recording Video

Once you have installed the DVR following the instructions in *Chapter 2 — Installation*, it is ready to record. The DVR will start recording based on the settings you made in the **Record** setup screen. See *Chapter 3 — Configuration*.

**Recycle On or Recycle Off.** The factory default is **Recycle On**. It does this by recording over the oldest video once the hard disk is full. Setting the DVR to **Recycle Off** causes it to stop recording once the hard disk is full.

**Standard or High.** The factory default resolution is **Standard**. When set to **Standard**, the DVR has a maximum recording speed of 120 ips. When set to **High**, the DVR has a maximum recording speed of 60 ips.

Pressing the **PANIC** button starts panic recording of all cameras, and pressing the button again stops panic recording. If you set the **Panic Recording Duration** in the **Record Screen**, panic recording will stop automatically according to the preset duration as long as the **PANIC** button is not pressed.

**NOTE: When the DVR is not in the Recycle mode and all available storage space has been used, panic recording will not operate.**

Although you will be able to record without changing the unit from its original factory settings, you will want to take advantages of the DVR's many tools. See *Chapter 3 — Configuration* for detailed descriptions of the recording mode options.

## Recording Audio

If the DVR was set up to record audio, it will record audio from up to two inputs when video is recording. The DVR will not record audio when the recording speed is set to less than 1 ips.

**NOTE: Make certain you comply with all local and federal laws and regulations when recording audio.**











## Playing Recorded Video


If a user who has **Search** authority logs into the system, the user can view recorded image. Once video has been recorded, you can view it by pressing the **PLAYBACK** button. When playing video for the first time, the DVR will display the most recent image. When playing video subsequent times, the DVR will start playing video from the last recalled image. Recorded audio will be played when the DVR displays a camera with recorded audio in full screen mode.


**NOTE: While recording video, the playback speed might decrease.**

**NOTE: Only the administrator and users with *Covert Camera View* authority can view video from covert cameras. The covert cameras in the playback mode are determined by the current camera settings.**




**Camera Buttons (1 to 16):** Pressing the individual camera buttons will cause the selected camera to display full screen.

**Arrow Buttons:** Pressing the  button plays video backward at high speed. Pressing the button again toggles the playback speed from ,  and . Pressing the  button plays video forward at high speed. Pressing the button again toggles the playback speed from ,  and . When in the pause mode, pressing the  button moves to the next image and pressing the  button moves to the previous image.

**PLAY/PAUSE Button:** Pressing the  button plays back images at regular speed or pauses playing video.

**CAMEO Button:** Pressing and holding the button for two seconds or longer enters the cameo mode. The yellow outline surrounding the video indicates the active cameo, and pressing the arrow buttons moves the active cameo. Pressing the desired camera button in the active cameo edits the cameo and displays the video of selected camera. Pressing the  (Play/Pause) button exits the Active Cameo mode. Selecting **Exit Group Edit** in the cameo menu displayed when pressing the **MENU/CAMEO** button also exits the Active Cameo mode.

**NOTE: A cameo is defined as any cell within multi-screen display. The cameo mode allows you to change the screen layout by editing the cameo.**


**PLAYBACK Button:** Pressing the **PLAYBACK** button enters the playback mode, and pressing the button again exits the playback mode. When entering the playback mode, video is paused. Pressing the  (Play/Pause) button plays back video at regular speed. The screen displays  when the DVR is in the Pause mode and the screen displays  when the DVR is playing back video.


**ZOOM Button:** Pressing the **ZOOM** button zooms in the current image on the screen.

**DISPLAY/SPOT Button:** Pressing the **DISPLAY/SPOT** button toggles different display formats. The available formats are: 2x2, 3x3 and 4x4. Pressing and holding the button for two seconds or longer allows you to select which cameras will display on the Spot monitor.








**GROUP Button:** Pressing the **GROUP** button changes the screen from the current camera group to the next camera group, and the screen displays page number.

You can use a mouse for convenient playback control. Position the mouse pointer on the playback screen, and the following playback toolbar will display.




Clicking  on the left side exits the toolbar. If you want to display the toolbar again, position the mouse pointer on the screen. Change the toolbar location by clicking the empty space on the right side of the toolbar and drag it to where you want it located on the screen.

The individual controls on the toolbar perform the following functions as described below:

- |   |                          |   |                    |
|---|--------------------------|---|--------------------|
|  | Go to the first image    |  | Fast backward play |
|  | Go to the previous image |  | Play               |
|  | Go to the next image     |  | Fast forward play  |
|  | Go to the last image     |   |                    |

## Searching Video

Pressing the **MENU** button or clicking the right mouse button while in the Playback mode displays the Search Menu.



- Go to the First — Displays the first recorded image
- Go to the Last — Displays the last recorded image
- Go to the Date/Time... — Searches by date and time (see below for more details)
- Calendar Search... — Searches using a calendar (see below for more details)
- Event Log Search... — Selects video from the event log (see below for more details)
- Text-In Search... — Searches text input strings (see below for more details)
- Motion Search... — Searches motion events (see below for more details)
- Clip-Copy... — Clips a video segment and saves it (see below for more details)
- Zoom... — Zooms the current playback image
- Slow Play... — Plays video at low speed (x1/2, x1/3, x1/4, x1/6 and x1/8)
- Exit Search — Exits the Search Menu

Figure 89 — Search menu.

**NOTE: While recording video, the playback speed of searched data might decrease.**

## Go to the Date/Time








Figure 90 — Go to the Date/Time screen.

Move the cursor over the date and time and press the  (Play/Pause) button. You can use the Left and Right arrow buttons to highlight the year, month, day, hours, minutes and seconds. Use the Up and Down arrow buttons to change to the date and time you want to search for video.

Once you have set the date and time you want, press the  button. Then highlight Go and press the  button. The selected date and time will display. (If no video was recorded during the selected time, a message appears alerting you that no image was recorded at that time.) The  button and arrow buttons can now be used to review the surrounding video.

## Calendar Search





Figure 91 — Calendar Search screen.





Days with recorded video display on the calendar with white numbers. You can highlight the days with recorded video by using the arrow buttons. Once you have highlighted a day, press the  (Play/Pause) button to select it.

A time bar displays at the bottom of the calendar. Hours in which video was recorded will be highlighted with blue. You can use the Up and Down arrow buttons to highlight the time bar. Once the time bar is highlighted, you can select the time by using the Left and Right arrow buttons.

**NOTE: The time bar is in one-hour segments. If a segment is highlighted, it means that some video was recorded during that hour. However, it does NOT mean video was recorded for the entire hour.**

If the DVR's time and date have been reset to a time that is earlier than some recorded video, it is possible for the DVR to have more than one video stream in the same time range. Move to **Select a Segment**, and select the video stream you want to search. Refer to the *Appendix D – Time Overlap* for further information on searching time-overlapped video streams.

**NOTE: The lower number of the Segment indicates the latest recorded video.**

Once you have set the date and time you want to search, highlight GO and press the  button. The selected date and time will display. The  button and arrow buttons can now be used to review the surrounding video.

**NOTE: It is possible that no recorded image displays on the current screen. Press the **DISPLAY** button and change the screen mode to 4x4. You will be able to easily see the camera have recorded video during target time.**

## Event Log Search









Time	Type	Title
03/26/2009 11:52:22	Text-In 1	
03/26/2009 11:52:15	Text-In 1	
03/26/2009 11:52:14	Motion 4	CAM4
03/26/2009 11:52:13	Motion 3	CAM3
03/26/2009 11:52:13	Motion 2	CAM2
03/26/2009 11:52:10	Motion 1	CAM1
03/26/2009 11:52:09	Video Loss 1 	CAM1
03/26/2009 11:52:08	Video Loss 1 	CAM1
03/26/2009 11:52:08	Alarm-In 1 	
03/26/2009 11:52:07	Alarm-In 1 	
Option...		
<div>   </div> <div>Close</div>		

Figure 92 — Event Log Search screen.

The DVR maintains a log of each time the Alarm Input port is activated. The Event Log Search screen displays this list. Use the arrow buttons to highlight the event for which you would like to see video.

The Event Log Search screen can also be accessed by pressing the **ALARM** button unless there is an alarm. There is no determined user authority to display the Event Log Search screen, however, the event video will not be played unless a user with **Search** authority logs into the system.

Pressing the  (Play/Pause) button will extract the event video and display the first image of the event. Pressing the  button will start playing the “event” video segment. Pressing **PLAYBACK** button returns to live monitoring.

**NOTE:** It is possible that no recorded image displays on the current screen. Press the **DISPLAY** button and change the screen mode to 4x4. You will be able to easily see the camera have recorded video during target time.

You can also narrow your event search by selecting the Option... button and setting up the new search condition.

The screenshot shows the 'Event Log Search Option' dialog box. It contains the following fields and options:

- From:** A dropdown menu with 'First' selected, and a date/time field showing '08/28/2007 11:53:43'.
- To:** A dropdown menu with 'Last' selected, and a date/time field showing '08/28/2007 11:53:43'.
- Check Time Overlap:** A checkbox that is checked.
- Alarm-In:** A dropdown menu with '1~16' selected.
- Motion:** A dropdown menu with '1~16' selected.
- Video Loss:** A dropdown menu with '1~16' selected.
- Text-In:** A dropdown menu with '1~16' selected.
- Record Channels:** A dropdown menu with '1~16' selected.
- Search Criteria (Right Side):** A list of checkboxes:
  - ☒ Panic Record
  - ☒ Check Recording
  - ☒ Check Alarm-In
  - ☒ Disk Almost Full
  - ☒ Disk Bad
  - ☒ Disk Temperature
  - ☒ Disk S.M.A.R.T.
- Buttons:** 'Search' and 'Cancel' buttons at the bottom right.

Figure 93 — Event Log Search Option screen.

You can search video from the first to last recorded images, or you can set the start and stop times and dates.

Highlight the box beside **From** and press the  $\odot$  button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the first recorded image.

Highlight the box beside **To** and press the  $\odot$  button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the last recorded image.

Highlight the box beside **Check Time Overlap** and press the  $\odot$  button. It toggles between On and Off. You will only be able to turn the Check Time Overlap on or off if a user-defined date and time is set to From and To. If the DVR's date and time have been reset, it is possible for the DVR to have more than one overlapping start and stop time. When set to On, you will be asked to select one of the overlapping start and stop time. When set to Off, the DVR will display search results from all start times to all stop times.

Highlight the box beside **Alarm-In** and press the  $\odot$  button. You can select the alarm inputs that you want to include in your search.

Highlight the box beside **Motion** and press the  $\odot$  button. You can select the cameras for which you want any reports of motion detection.

Highlight the box beside **Video Loss** and press the  $\odot$  button. You can select the cameras for which you want any reports of lost video.

Highlight the box beside **Text-In** and press the  $\odot$  button. You can select the text-in devices which you want any report of text input.

Highlight the box beside **Record Channels** and press the  $\odot$  button. You can select the cameras that you want to search for any reports of event recorded data. The DVR will display the events (not the camera channels) that occurred and that also are recorded on the camera channel that you selected. If you do not select a camera channel in this field, the DVR will search events that are not associated with cameras.

You can also toggle On and Off self-diagnostic events as part of your search. The choices are:

- Panic Record
- Check Recording
- Check Alarm-In
- Disk Almost Full
- Disk Bad
- Disk Temperature
- Disk S.M.A.R.T.

Once you set your desired search conditions, highlight Search and press the  button to display the search results in the Event Log Search screen. Selecting Cancel exits the screen without saving the changes.

## Text-In Search





Text-In Search	
Time	Transaction
08/28/2007 11:56:49	total : \$ 8.30
08/28/2007 11:56:48	=====
08/28/2007 11:56:47	Garlic bread   \$ 1.15   1(s)   \$ 1.15
08/28/2007 11:56:47	Pan cake   \$ 3.15   1(s)   \$ 3.15
08/28/2007 11:56:46	7 Up   \$ 1.80   1(s)   \$ 1.80
08/28/2007 11:56:45	Coke   \$ 2.20   1(s)   \$ 2.20
08/28/2007 11:56:44	=====
08/28/2007 11:56:44	Item Unit price Qty amount
08/28/2007 11:56:43	=====
08/28/2007 11:56:42	abc Market 2003.01.01 AM 09:00
Option...  	
Close	

Figure 94 — Text-In Search screen.

The DVR maintains a log of each time there is Text Input. The Text-In Search screen displays this list. Use the arrow buttons to highlight the event for which you would like to see video.

Pressing the  (Play/Pause) button will extract the video associated with the Text Input and display the first image of the event. Pressing the  button will start playing the “event” video segment. Pressing **PLAYBACK** returns to live monitoring.

**NOTE:** It is possible that no recorded image displays on the current screen. Press the **DISPLAY** button and change the screen mode to 4x4. You will be able to easily see the camera have recorded video during target time.

**NOTE:** Text Input information will be overlaid on the image while the recorded video is played at regular speed.

You can also narrow your event search by selecting the Option... button and setting up the new search condition.

The screenshot shows the 'Text-In Search Option' dialog box. It has fields for 'From' (checked 'First', date/time '12/03/2007 13:57:10'), 'To' (checked 'Last', date/time '12/03/2007 13:57:10'), and 'Channels' (set to '1~16'). Below these is a dropdown menu for 'Generic Text'. A table with 7 columns (No., -, Name, Comp., Value, Column, Line) and 5 rows is shown. The first row has values: No. 1, -, -, Name, Comp., Value, Column 0, Line 0. Below the table is a '+' button and a 'Case Sensitive' checkbox. At the bottom are 'Load', 'Save', 'Search', and 'Cancel' buttons.

No.	-	Name	Comp.	Value	Column	Line	
1	-		-		0	0	X
	-		-		0	0	X
	-		-		0	0	X
	-		-		0	0	X
	-		-		0	0	X

Figure 95 — Text-In Search Option screen.

You can search video from the first to last recorded images, or you can set the start and stop times and dates.

Highlight the box beside **From** and press the  $\odot$  button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the first recorded image.

Highlight the box beside **To** and press the  $\odot$  button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the last recorded image.

Highlight the **Channel** and press the  $\odot$  button. Select the text-in devices that you want to search for text input.

Highlight the text input device box and press the  $\odot$  button. Select your Text Input Device from the list.

Highlighting the + and pressing the  $\odot$  button allows you to add a new set of search parameter. Set up the desired search parameter. Refer to the *Appendix B – Text-In Search Examples* for further information on setting up search parameters. The X column can be used to delete a set of search parameter or entire sets of search parameters.

Highlight **Case Sensitive** and press the  $\odot$  button. This will toggle between On and Off. When this feature is On, the search will find only those text strings in which the case matches.

Highlight **Load** and press the  $\odot$  button to load saved search option settings. Select the desired search option settings.

Highlight **Save** and press the  $\odot$  button to save the current search option settings. A virtual keyboard appears that you can use to enter the search option name.

Once you set your desired search conditions, highlight **Search** and press the  $\odot$  button to display the search results in the **Text-In Search** screen. Selecting **Cancel** exits the screen without saving the changes.

## Motion Search







Figure 96 — Motion Search screen.

The **Motion Search...** can be selected from the Search menu while the DVR displays the camera full screen. The **Motion Search** screen displays a list of motion events. Use the arrow buttons to highlight the event for which you would like to see video and press the  (Play/Pause) button to display the video associated with the selected event on the small search screen.

Highlighting **Close** and pressing the  button will extract the video associated with the Motion event and display the first image of the event. Pressing the  button will start playing the “event” video segment. Pressing **PLAYBACK** returns to live monitoring.

You can also narrow your event search by selecting the **Option...** button and setting up the new search condition.








Figure 97 — Motion Search Option screen.

You can search video from the first to last recorded images, or you can set the start and stop times and dates.

Highlight the box beside **From** and press the  button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the first recorded image.

Highlight the box beside **To** and press the  button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the last recorded image.


Highlight the box beside **Type** and press the  button. You can select between **Motion Search** and **Museum Search**. **Motion Search** detects motion in the defined area. **Museum Search** detects if a defined object has moved.


Highlight the box beside **Zone** and press the  button. An image from the video appears with a grid overlaid. You can turn sensor blocks On and Off to define the area of the picture in which you want to search for motion.

**NOTE: Defining the area of the image in which you want to search for motion is nearly identical to setting up the DVR for Motion Detection. Please refer to *Motion Detection Screen* in *Chapter 3 — Configuration* for more detailed instructions on setting up the detection blocks.**

**NOTE: When setting the Museum Search Zone, the zone should be placed inside of the border line of the target object. If the selected block is placed on the border line, the sensitivity of the Museum Search may decrease.**

The zone should be placed or focused on the centre or, at least, within the outline of targeted object.

Highlight the box beside **Sensitivity** and press the  button. You will be able to select from 1 (low sensitivity) to 5 (high sensitivity).

Highlight the box beside **Min. Blocks** and press the  button. You will be able to set the number of sensor blocks that must be activated. Setting the Min Blocks will only be available if Motion Search is selected.


Once you set your desired search conditions, highlight **Search** and press the  button to display the search results in the **Motion Search** screen. Selecting **Cancel** exits the screen without saving the changes.

When you search for motion events of another camera, you will be asked whether or not you want to delete the previous search results from the list.

## Clip-Copy Screen

The **Clip-Copy** screen can be used to copy video clips to an internal CD-RW or DVD RW drive, or external USB hard disk, CD-RW or flash drive. The copied video clips can be viewed on computers running Microsoft Windows 98, ME, 2000, XP or Vista. Refer to the *Appendix A — USB Hard Disk Drive Preparation* for information on preparing the external drive for clip copy. The clip copy can be simply done by pressing the **CLIP COPY** button.

Press the **CLIP COPY** button while in the Live monitoring mode, and the **Clip-Copy** screen appears to allow clip copy setup.

Pressing the **CLIP COPY** button during the playback will set the starting point of the video to be clip copied, and the  icon displays at the bottom-left corner of the screen. Pressing the **CLIP COPY** button again will set the ending point of the video to be clip copied by displaying the **Clip-Copy** screen.

Pressing and holding the **CLIP COPY** button for more than two seconds while in the Playback mode or Live Monitoring mode initiates the One-Touch Clip Copy function. The last recorded image will be the ending point of video to be clip copied, and the system will automatically begin to calculate the possible video data size that the selected storage media can handle.




Figure 98 — Clip-Copy screen.

You can search video from the first to last recorded images, or you can set the start and stop times and dates.

Highlight the box beside **From** and press the (Play/Pause) button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the first recorded image.

Highlight the box beside **To** and press the button to toggle between On and Off. When set to Off, you can enter a specific Date and Time. When set to On, the search will be from the last recorded image.

Highlight the box beside **Channels** and press the button. You can select the cameras that you would like to include in your video clip.

Highlight the box beside **Password** and press the button. A virtual keyboard appears allowing you to enter the password for reviewing the video clips.

Highlight the box beside **Dest.** and press the button. You can select the storage device on which you would like to record the video clip. You can choose from Internal CD-RW, Internal DVD RW, USB Storage and USB CD-RW.

**CAUTION: The USB device for clip copy must be FAT 16 or FAT32 format.**


**NOTE: While copying video clips on the CD-RW or DVD RW, the recording speed might decrease.**


**NOTE: When the error message “Firmware update of the optical drive is required” displays, update the firmware of the installed CD-RW drive or DVD RW drive. Please follow the instructions described in Chapter 3 – Configuration – System Information section.**

The DVR automatically assigns a file name to the video clip. However, you can give the video clip file a different name. Highlight the box beside **File Name** and press the button. A virtual keyboard appears. Enter a file name for the video you are backing up and select **Close**. The DVR will automatically add the camera number (for example “01”) and “.exe” to the file name.

**NOTE: When naming a file, you cannot use the following characters: \, /, :, \*, ?, “, <, >, |.**

Highlight **Include Text-In Data** and press the button. This will toggle between On and Off. When this feature is On, you can include text-in data when copying video if the video was recorded with text-in data.

Highlight **Verify After Burning** and press the  button. This will toggle between On and Off. When this feature is On, you can verify that the data is written on the CD-RW or DVD RW properly.


Once you have given the video clip a file name, highlight the **Start** button and press the  button. The confirmation screen displaying data size will appear. When the storage device does not have enough space, the DVR will ask if you want to copy as much of the video clip as possible in the available space.

Highlight the **Continue** button and press the  button to continue clip copy.

Once the clip copy starts, you can cancel it by selecting **Cancel** or hide the screen by selecting **Close**. When selecting **Close**, Clip Copy continues and a confirmation screen will display when complete.

**NOTE: Only 4.7GB DVD media is available. To clip copy video on the DVD media using remaining space, the size of previously recorded data on the DVD media should be less than 4GB.**

**NOTE: The file size for clip copy is limited to 2GB.**

You can use other functions on the DVR while video is being backed up. To do this, highlight the **Close** button and press the  button. You can return to the **Clip-Copy** screen at any time to check the progress.

You do not need to install any special software on your personal computer to review the video clips. Refer to the RAS manual for instructions on how to review video clips you have copied.

**NOTE: During Clip Copy, you cannot shut the system down, clear data on the storage device, or format the storage device.**

**CAUTION: Do NOT disconnect the USB cable or the power from the external drive while copying video clips. If the external drive is shut down or the USB cable is disconnected while copying video clips, THE DVR SYSTEM MAY NOT WORK NORMALLY OR THE EXTERNAL DRIVE COULD BE DAMAGED, and you will get an error message the next time you try to copy video clips. You will need to power down the DVR and restart it to get rid of the error message. Once the file system of the USB hard disk drive has been corrupted, this error message cannot be dismissed. Even after restarting the DVR it may automatically restart while preparing to clip copy. You must recover the file system using the recovery program, or you must reformat the hard disk drive.**



## Appendix A — USB Hard Disk Drive Preparation

### Preparing the USB hard disk drive in Windows 2000

**NOTE: Preparing a USB hard disk drive under Windows XP and Windows Vista is almost identical to Windows 2000.**

1. Connect the USB hard disk drive to your computer using the USB Cable.
2. Turn on your computer.
3. The USB device icon should display on the Taskbar.
4. If the USB hard disk drive is partitioned or has data, it will show up in *My Computer* as a hard disk drive icon. Check the file system by right clicking on the icon and checking under *Properties > General > File System*. If the file system is NOT FAT32 format, format the USB hard disk drive using the FAT32 format.
5. If the USB hard disk drive is not partitioned, go to *Administrative Tools* in *Control Panel* and launch *Computer Management*. Open *Disk Management* in *Storage* and right click an unallocated region of the USB hard disk drive. Then, click *Create Partition*.
6. In the *Create Partition* wizard, click *Next* then *Primary Partition*, and follow the instructions on the screen. Make sure that the FAT32 is selected for the file system.

**NOTE: The partition size should be less than 32GB because of Microsoft limitations.**

After formatting is complete, the USB hard disk drive will be added to *My Computer*.

7. Connect the USB hard disk drive to the DVR.

### Preparing the USB hard disk drive in Windows 98

**NOTE: Preparing a USB hard disk drive under Windows ME is almost identical to Windows 98.**

1. Connect the USB hard disk drive to your computer using the USB Cable.
2. Turn on your computer. The *Add New Hardware wizard* window will appear.
3. Install the device driver for the USB backup device following the instructions provided with your USB hard disk drive.
4. If the USB hard disk drive is partitioned or contains data, it will show up in *My Computer* as a hard disk drive icon. Check the file system in *Properties > General > File System*. If the file system is NOT FAT32 format, format the USB hard disk drive with FAT32 format.
5. Run the FDISK utility by clicking *Start* then *RUN*. Type “fdisk” and click OK.
6. When the MS-DOS command prompt appears, type “Y” and hit the enter key.
7. In the FDISK Option menu, choose “5. Change current fixed disk drive.”
8. Choose the appropriate letter corresponding to the USB hard disk drive.
9. In the FDISK Option menu, choose “1. Create DOS partition or Logical DOS Drive.”
10. In the Create DOS Partition or Logical DOS Drive menu, choose “1. Create Primary DOS Partition.” And Type “Y” to use all available space and hit the enter key. Hit ESC to exit the screen after the USB hard disk drive partition is created.
11. Restart your computer and verify the newly created drive is in *My Computer*.
12. Right click the newly created hard disk drive icon and select “Format”.
13. In the Format Screen, select “Full” as the “Format type” and click “Start”.
14. After formatting is complete, connect the USB hard disk drive to the DVR.

## Appendix B — Text-In Search Examples

### Search Example I

1 2 3 4 5 6  
12345678901234567890123456789012345678901234567890

Item	Unit price	Qty	amount
Coke	\$ 2.20	1 (s)	\$ 2.20
Fanta	\$ 2.20	1 (s)	\$ 2.20
Hotdog	\$ 3.50	3 (s)	\$ 10.50
Pepsi	\$ 1.95	1 (s)	\$ 1.95
total : \$			16.85

Thank you~~

In the above text-in data, you can find that the comparison value is located at 17<sup>th</sup> (Unit price, \$ mark will be ignored automatically), 28<sup>th</sup> (Qty) and 40<sup>th</sup> (amount) characters (including spaces) from the left. In this case, you can enter “17”, “28” and “40” in each Column box.

For example, if you want to search for Coke with a Qty (Quantity) of more than 1 and Hotdog with an amount totaling over \$8, the following search condition can be set.

Text-In Search Option

From ☒ First 12/03/2007 13:57:10
To ☒ Last 12/03/2007 13:57:10
Channels 1~16
Generic Text

No.	-	Name	Comp.	Value	Column	Line	X
1		Coke	>	1	28	0	X
2	AND	Hotdog	>	8	40	0	X
					0	0	X
					0	0	X
					0	0	X

+
☐ Case Sensitive

Load Save Search Cancel

### Search Example II

1 2 3 4 5 6  
12345678901234567890123456789012345678901234567890

Item	Unit price	Qty	amount
Coke	\$ 2.20	1 (s)	\$ 2.20
Fanta	\$ 2.20	1 (s)	\$ 2.20
Hotdog	\$ 3.50	3 (s)	\$ 10.50
Pepsi	\$ 1.95	1 (s)	\$ 1.95
total : \$			16.85

Thank you~~

In the above text-in data, you can find that the comparison value is located at 17<sup>th</sup> (Unit price, \$ mark will be ignored automatically), 28<sup>th</sup> (Qty) and 40<sup>th</sup> (amount) characters (including spaces) from the left, but the value of **amount** category is located on a different line from **Item**. In this case, you can enter “17”, “28” and “40” in each **Column** box and enter “1” in the **Line** box for the next line.

For example, if you want to search for Coke with a **Qty** (Quantity) of more than 1 and Hotdog with an **amount** totaling over \$8, the following search condition can be set.

**Text-In Search Option**

From ☒ First 12/03/2007 13:57:10

To ☒ Last 12/03/2007 13:57:10

Channels 1~16

Generic Text

No.	-	Name	Comp.	Value	Column	Line	X
1		Coke	>	1	28	0	X
2	AND	Hotdog	>	8	40	1	X
					0	0	X
					0	0	X
					0	0	X

+ ☐ Case Sensitive

Load Save Search Cancel

## Appendix C — WebGuard

WebGuard allows you to access a remote DVR, monitor live video images and search recorded video using Internet Explorer web browser anytime from virtually anywhere.

Computer system requirements for using the WebGuard program are:

- Operating System: Microsoft® Windows® 2000, Microsoft® Windows® XP or Microsoft® Windows® Vista
- CPU: Intel Pentium III (Celeron) 600MHz or faster
- RAM: 128MB or higher
- VGA: 8MB or higher (1024x768, 24bpp or higher)
- Internet Explorer: Version 6.0 or later

Start Internet Explorer on your local PC. You can run the WebGuard program by entering the following information in the address field.

- “http://IP address:port number” (The DVR IP address and the WebGuard port number (default: 12088) set in the Network setup screen (WebGuard tab))
- Or, “http://DVRNS server address/DVR name” (The DVRNS server address and the DVR name registered on the DVRNS server)
- Or, “http://www.dvronline.net” (Entering the DVR IP address or the DVR name will be required when logging in)

**NOTE: WebGuard only works with Microsoft Internet Explorer and will NOT work with Netscape or other browsers.**




Figure 99 — WebGuard login screen.

Select between the WEBWATCH (Web monitoring) and WEBSEARCH (Web search) modes and enter the appropriate port number of the program. Entering ID and PASSWORD and clicking the [LOGIN] button logs in using the selected mode. Selecting Save ID saves the ID you entered.

You will need to enter the DVR IP address in the DVR ADDRESS field when running the WebGuard program by entering <http://www.dvronline.net>. Selecting the Use DVRNS option allows you to enter the DVR name registered on the DVRNS server instead of the IP address. You must enter the DVRNS server address and port number in the SETUP setting when selecting the Use DVRNS option.

**NOTE: The port numbers for WATCH and SEARCH should be the same with port numbers for Remote Watch and Remote Search set during Network setup.**

**NOTE: When running the updated WebGuard for the first time, Internet Explorer might occasionally load the information of the previous version. In this case, delete the temporary internet files by selecting Tools → Internet Options → General tab, and then run WebGuard again.**

**NOTE: There might be a problem that the bottom of WebGuard page is cropped due to the address or status bars in Microsoft Internet Explorer 7.0. In this situation, it is recommended that websites open windows without address or status bars by changing the internet setting. (Go to the Tools → Internet Options → Security tab → Click the Custom level... button → Select *Enable* for the *Allow websites to open windows without address or status bars* option)**

**NOTE:** When running WebGuard in the Microsoft Windows Vista operating system, it is recommended to start Internet Explorer with elevated administrator permissions. Click the right mouse button on the Internet Explorer icon and select the *Run as administrator* option from the context menu. Otherwise, some functions of WebGuard might be limited.

**NOTE:** There might be a problem with screen display or screen update due to low image transmission speed when using the Microsoft Windows Vista operating system. In this situation, it is recommended you disable the Auto Tuning capability of your computer. Run the Command Prompt with elevated administrator permissions (Go to the Start Menu → Accessories → *Command Prompt* → Click the right mouse button and select the *Run as administrator* option). Then enter “netsh int tcp set global autotuninglevel=disable” and hit the enter key. Restart your computer to apply the changes. If you want to enable the Auto Tuning capability again, enter “netsh int tcp set global autotuninglevel=normal” after running the Command Prompt with elevated administrator permissions. Restart your computer to apply the changes.

## Web Monitoring Mode

WebWatch is a remote web monitoring program that allows you to monitor live video transmitted in real-time from the remote DVR.












Figure 100 — WebWatch screen.

- ① Click the  to log out the WebGuard program.
- ② Click the  to access to the web search mode.
- ③ Position the mouse pointer on the WebWatch logo to see the version of the WebGuard program.
- ④ The DVR information window displays the login information of WebGuard.
- ⑤ Click the screen format to select the desired display mode. When changing the screen format, the selected camera on the current screen will be located in the first cell of the new layout.
- ⑥ Click the camera button (1 to 16) to select the camera to be viewed.

- ⑦ Click the  to adjust the brightness, contrast, saturation and hue of monitoring image.
- ⑧ Click the  to control pan, tilt and zoom of the camera from a remote site.
- ⑨ Click the  to control alarm out devices at the remote site.



- ⑩ Click the  to save the current image as a bitmap or JPEG file format.
- ⑪ Click the  to set up the image drawing mode and OSD display. You can adjust the display speed by changing the image drawing mode, and select OSD information to be displayed on the screen.
- ⑫ The event status window at the bottom displays a list of events that were detected from the remote site.
- ⑬ Selecting a camera on the screen and clicking the right mouse button allows you to change the camera name and the image aspect ratio displayed on each camera screen, and to enhance image display quality by eliminating stair stepping (aliasing) effects in the enlarged image.



**NOTE:** A camera name change in the Web Watch mode does not affect the camera name set up on the remote site. Leaving the Camera Title blank causes the camera name set up on the remote site to display.

## Web Search Mode

WebSearch is a remote web search program that allows you to search recorded video on the remote DVR.

**NOTE:** The remote site connection in the Web Search mode will automatically be disconnected if there is no activity for 30 minutes.


















Figure 101 — WebSearch screen.

- ① Click the  to log out the WebGuard program.
- ② Click the  to access to the web monitoring mode.
- ③ Position the mouse pointer on the WebSearch logo to see the version of the WebGuard program.
- ④ The DVR information window displays the time information of recorded data on the remote DVR and login information of WebGuard.
- ⑤ Click the  to blur, sharpen, equalize and interpolate playback images. Click the  to zoom out or zoom in the recorded image. Click the  to adjust the brightness of the recorded images.



**NOTE: Image processing works only in the pause mode.**


- ⑥ The playback function buttons include fast backward, pause, play, fast forward, go to the first image, go to the previous image, go to the next image, and got to the last image.
- ⑦ Click the screen format to select the desired display mode.
- ⑧ Click the  to enter the time-lapse search mode which allows you to search for recorded data by time and then play back images found within the time parameters. The Timetable window located at the bottom displays the time information for the image of the date selected on the calendar. If more than one video stream in the same time range, you can select the video stream you want to search. Clicking a specific time displays the image recorded at that time on the screen. Selecting the  allows you to display an image from a specific time.
- ⑨ Click the  to enter the event search mode which allows you to search for event log entries using specific conditions and play back the images associated with those event entries.
- ⑩ Click the  to save any video clip of recorded data as an executable file, or click the  to save the current image in a bitmap or JPEG file format. Click the  to print the current image on a printer connected to your computer.
- ⑪ Click the  to set up the image drawing mode and OSD display. You can change the display speed by adjusting the image drawing mode, and select OSD information to display on the screen.
- ⑫ Click the  to reload the recording data.
- ⑬ The timetable displays recorded data of the selected camera by time (in hour segments).
- ⑭ Selecting a camera on the screen and clicking the right mouse button allows you to change the camera name, play audio while playing back recorded video that has recorded audio (single-screen layout only) and the image aspect ratio displayed on each camera screen, and to enhance image display quality by eliminating stair stepping (aliasing) effects in the enlarged image.



**NOTE: A camera name change in the Web Search mode does not affect the camera name set up on the remote site. Leaving the Camera Title blank causes the camera name set up on the remote site to display.**

## Appendix D — Time Overlap

If the DVR's time and date have been reset to a time that is earlier than the existing recorded video, it is possible for the DVR to have more than one video stream in the same time range. In this case, you can search overlapping video streams individually by selecting a specific segment. For example, when the DVR has recorded video from one to five o'clock and the user changes the time backward from five to three o'clock and then continues recording until six o'clock, there will be two video streams and segments from three to five o'clock.



You can search overlapping video streams by selecting a specific time or time range. If you want to search recorded video at four o'clock during the overlapping time range using a search menu such as **Go to the Date/Time**, select the segment you want to search.

Select a Segment
1: Segment 2
2: Segment 1






If you want to search recorded video from four to five o'clock during the overlapping time range using a search menu such as **Event Log Search**, **Text-In Search** or **Motion Search**, it is possible for the DVR to have two overlapping start and stop times. You will be asked to select one of the overlapping start and stop times from the search time ranges as follows:

Select a Range
1: Scope 1 ~ 1
2: Scope 1 ~ 2
3: Scope 2 ~ 2

- From four o'clock of the first segment to five o'clock of the first segment
- From four o'clock of the first segment to five o'clock of the second segment
- From four o'clock of the second segment to five o'clock of the second segment




## Appendix E – Troubleshooting

Problem	Possible Solution
No Power	<ul style="list-style-type: none"> <li>• Check power cord connections.</li> <li>• Confirm that there is power at the outlet.</li> </ul>
No Live Video	<ul style="list-style-type: none"> <li>• Check camera video cable and connections.</li> <li>• Check monitor video cable and connections.</li> <li>• Confirm that the camera has power.</li> <li>• Check camera lens settings.</li> </ul>
Live Video Very Bright	If a cable is attached to the “Loop” connector, make certain it is connected to a properly terminated device.
DVR has stopped recording	If hard disk drive is full, you will either need to delete video or set the DVR to the Overwrite Mode.
The icon  displays, however, the DVR is not recording.	When the DVR is in the Pre-Event recording mode, the yellow  and  display when there is no event, and the DVR is not recording. The red  and  display when any event occurs and the DVR starts recording.

# Appendix F — Connector Pin Outs

## I/O Connector Pin Outs




AI (1 to 16)	Alarm Inputs 1 to 16
GND	Chassis Ground (5 connectors)
NC	Relay Alarm Outputs (Normally Closed)
NO	Relay Alarm Outputs (Normally Open)
C	Relay Common
ARI	Alarm Reset In

## RS485 Connector Pin Outs



Master Unit	Slave Unit
RX-/TX- → To → TX-/RX-	
RX+/TX+ → To → TX+/RX+	

## Appendix G – Map of Screens



## Appendix H – System Log Notices

Boot Up	Schedule On
Shutdown	Schedule Off
Restart	Panic On
Upgrade	Panic Off
Upgrade Fail	Clear All Data
Power Failure	Clear Disk
Time Change	Format Disk
Time Zone Change	Disk Full
Time Sync	Auto Deletion
Time Sync Fail	Search Begin
Disk Bad	Search End
Login	Clip-Copy Begin
Logout	Clip-Copy End
Setup Begin	Clip-Copy Cancel
Setup End	Clip-Copy Fail
Remote Setup Change	Clip-Copy User:
Remote Setup Fail	Clip-Copy From:
Setup Imported	Clip-Copy To:
Setup Import Failure	Clip-Copy Duration of Video:
Setup Exported	Clip-Copy Camera:
Setup Export Failure	Callback Fail
Setup Export Cancel	

## Appendix I – Error Code Notices

System Upgrade Related		Clip Copy Related	
No.	Description	No.	Description
0	Unknown error.	0	Unknown error.
1	File version error.	1	Device error.
2	Operating system version error.	2	Mounting failed.
3	Software version error.	3	No media.
4	Kernel version error.	4	Invalid media.
100	Upgrade device mounting failed.	5	File already existed.
101	Package is not found.	6	Not enough space.
102	Extracting package failed.	7	Creating temporary file failed.
103	LILO failed.	8	Opening disk failed.
104	Rebooting failed.	9	Formatting disk failed.
105	Invalid package.	10	Database has been changed.
106	ODD firmware upgrade failed.	11	Appending failed.
300	Remote connection failed.	12	Bad sector.
301	Remote network error.	13	No executable file.
302	Remote upgrade is not authorized.	14	Opening executable file failed.
303	Saving remote package failed.	15	Writing executable file failed.
304	Remote upgrade is cancelled by the user.	16	Creating image failed.
400	USB device mounting failed.	17	Burning failed.
401	Reading upgrade package on the USB device failed.	18	Burning is out of time.
402	Copying upgrade package on the USB device failed.	22	Verify failed.
500	System is busy clip copying.		

## Appendix J — Specifications

VIDEO	
Signal Format	NTSC or PAL (Auto Detect)
Video Input	Composite: 8 or 16 looping inputs, 1 Vp-p, auto-terminating, 75 Ohms
Monitor Outputs	Composite: 1 BNC, 1 Vp-p, 75 Ohms SPOT: 1 BNC, 1 Vp-p, 75 Ohms VGA: 1
Video Resolution	Composite: 720x480 (NTSC), 720x576 (PAL) VGA: 800x600 @ 60Hz
Playback/Record Speed (images per second)	120/120ips (NTSC), 100/100ips (PAL)

INPUTS/OUTPUTS	
Alarm Input	8 or 16 terminal, programmable as NC or NO, 2.4V (NC) or 0.3V (NO) threshold, 5VDC
Alarm Output	2 relay output, programmable as NC or NO, 2A@125VAC, 1A@30VDC
Alarm Reset Input	1 TTL, terminal block
Internal Buzzer	80dB at 10cm
Network Connectivity	10/100 Mbps Ethernet (RJ-45), RS232C for external modem
Audio Input	RCA Input: 2, Line In
Audio Output	RCA Output: 1, Line Out
Text Input	POS Interface, ATM Interface

CONNECTORS	
Video Input	Composite: 8 or 16 BNC
Video Loop	Composite: 8 or 16 BNC (Auto Terminating)
Monitor Output	Composite: 1 BNC VGA: 1 VGA SPOT (Composite): 1 BNC
Audio In	2 RCA connector
Audio Out	1 RCA connector
Alarm Input/Output	Terminal blocks
Ethernet Port	RJ-45
RS232C Serial Port	DB9 (P)
RS485 Serial Port	Two-connector terminal block
USB Port	2 (USB 2.0)

STORAGE	
Primary Storage	SATA hard disk drive (up to 4) (up to 3 with an internal CD-RW drive or DVD RW drive)
Secondary Storage*	Built-in CD-RW drive USB hard disk drive, CD-RW drive or flash drive

\* When installing an internal CD-RW drive or DVD RW drive, connect the SATA I/O cable to the SATA3 socket.

Specifications are subject to change without notice.

GENERAL	
Dimensions (W x H x D)	16.9" x 3.5" x 15.7" (430mm x 88mm x 400mm)
Unit Weight	16.1 lbs. (7.3kg)
Shipping Weight	25.6 lbs. (11.6kg)
Shipping Dimensions (W x H x D)	21.3" x 11.4" x 23.2" (540mm x 290mm x 590mm)
Operating Temperature	41°F to 104°F (5°C to 40°C)
Operating Humidity	0% to 90%
Power	100 – 240 VAC, 4 – 2 A, 60/50Hz
Power Consumption	Max. 65W (75W when 4 hard disk drives are installed)
Approvals	FCC, UL, CB, CE

Specifications are subject to change without notice.

## **WEEE (Waste Electrical & Electronic Equipment)**

### ***Correct Disposal of This Product***

***(Applicable in the European Union and other European countries with separate collection systems)***



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.