





# Quick Installation Guide 4/8/16 Channel DVR

## 1 Connecting A Video Display


This DVR supports 3 types of video output interfaces including VGA, HDMI and BNC.  
Connect any one of them for a video display.



Plug a VGA cable from VGA monitor into the port marked "VGA" on the back of the DVR.



Plug an HDMI cable from High Definition Television into the port marked "HDMI" on the back of the DVR.




Connect a BNC-to-RCA cable to the "Video Out" port on the back of the DVR.  
Plug the RCA end into the "Video In" port of the television.

## 2 Connecting Cameras


### Step 1.

Connect the BNC / Power from the camera to the matching connector on the extension cable.




### Step 2.

Connect the BNC connector on the extension cable to any of the "Video In" ports on the back of the DVR.



### Step 3.

Plug one of the power leads on the power splitter into the power lead on the extension cable.  
Connect the single end of the power splitter to the power adapter.  
Or if you are connecting only a single camera, connect the power lead to the power adapter directly.



## 3 Plug USB Mouse into DVR


Connect a USB mouse to the USB port on the back of the DVR for DVR control.



## 4 Power on DVR

Plug in the DVR to power up.  
You will need to press a power switch on the back of the DVR to turn on.



 **Safety Precautions:**  
Do Not touch or remove electrical parts, wires and HDD during operation.